FOXWELL®

Function List

AutoMaker:Honda
Version:V5.00

NOTES:
√ This function is supported.
○ This function is not supported.
※ This function may be supported, which depends on the actual condition of the vehicle.
▲ This function is the new feature in this version.
As for special function please refer to the special function table.

System Name	ECU Info	Read Codes	Erase Codes	Live Data	Freeze Frame
PGM-FI	√	√	√	√	√
DIESEL	√	√	√	√	√
A/T	√	√	√	√	√
CVT	√	√	√	√	√
ABS	√	√	√	√	※
SRS	√	√	√	√	○
EPS	√	√	√	√	√
POP-UP HOOD	√	√	√	√	
IMA	√	√	√	√	√
IMMOBI	○	○	○	√	○
KEYLESS ACCESS (RL)	√	√	√	√	○
EVPS	√	√	√	√	√
CMS	√	√	√	√	√
ACM	√	√	√	√	√
TPMS	√	√	√	√	
SH-AWD	√	√	√	√	√
VTM 4	√	√	√	√	√
LKAS CAMERA	√	√	√	√	√
LKAS CONTROL	√	√	√	√	√
iNVS	√	√	√	√	√
Honda Smart Parking	√	√	√	√	√
Adaptivecontrol(ACC)cruise	√	√	√	√	√
Hydraulic booster	√	√	√	√	○
Active Damper System	√	√	√	√	√
4WS	√	√	√	√	√
DBW	√	√	√	√	√
ATTS	√	√	√	√	√
i-SHIFT	√	√	√	√	○
R/C ENG STARTER	○	○	○	○	○
BODY ELECTRICAL	√	√	√	√	
BSI	√	√	√	√	
Electric Parking Brake	√	√	√	√	
MVCS	√	√	√	√	
PCU	√	√	√	√	
SVT	√	√	√	√	