

AutoMaker: Mazda
Version: V1.00

NOTES:

- ✓ This function is supported.
 - This function is not supported.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
 - ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	4X4	✓	✓	✓	✓	○
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	ABS	✓	✓	✓	✓	8
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	GEM	✓	✓	✓	✓	000A 000F
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	IC	✓	✓	✓	✓	○
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	PAM	✓	✓	✓	✓	○
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	PCM	✓	✓	✓	✓	0009 0023 0025 00C5
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	RCM	✓	✓	✓	✓	000C
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	4X4	✓	✓	✓	✓	○
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	ABS	✓	✓	✓	✓	8
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	GEM	✓	✓	✓	✓	000A 000F
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	IC	✓	✓	✓	✓	5
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	PAM	✓	✓	✓	✓	○
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	PCM	✓	✓	✓	✓	0009 0023 0025 00C5
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	RCM	✓	✓	✓	✓	000C
626 / 626 WAGON / TELSTAR	1.8L	FP	1997 - 2000	PCM	✓	✓	✓	✓	0023 0025

626 / 626 WAGON / TELSTAR	1. 8L	FP	1999	ABS	✓	✓	✓	✓	○
626 / 626 WAGON / TELSTAR	1. 8L	FP	2000	ABS/TCS	✓	✓	✓	✓	○
626 / 626 WAGON / TELSTAR	2. 0L	FS	1997 - 1999	ABS	✓	✓	✓	✓	○
626 / 626 WAGON / TELSTAR	2. 0L	FS	1997 - 2001	PCM	✓	✓	✓	✓	0023 0025
626 / 626 WAGON / TELSTAR	2. 0L	FS	1998 - 2001	ABS/TCS	✓	✓	✓	✓	○
626 / 626 WAGON / TELSTAR	2. 0L	RF-T	1997 - 2000	PCM	✓	✓	✓	✓	○
626 / 626 WAGON / TELSTAR	2. 0L	RF-T	1999 - 2000	ABS	✓	✓	✓	✓	○
626 / 626 WAGON / TELSTAR	2. 5L	KL	1997 - 2001	PCM	✓	✓	✓	✓	0023 0025
626 / 626 WAGON / TELSTAR	2. 5L	KL	1998 - 2001	ABS/TCS	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 0L	LF	2007	ABS	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 0L	LF	2007	BCM/GEM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 0L	LF	2007	EATC	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 0L	LF	2007	EPS	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 0L	LF	2007	IC	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 0L	LF	2007	ICCM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 0L	LF	2007	LCM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 0L	LF	2007	MPM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 0L	LF	2007	PCM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 0L	LF	2007	RCM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 0L	LF	2007	RKE	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 0L	LF	2007	RVM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 0L	LF	2007	TCM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 5L	L5	2007	4X4	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 5L	L5	2007	ABS	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 5L	L5	2007	BCM/GEM	✓	✓	✓	✓	○

ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007	EATC	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007	EPS	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007	IC	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007	ICCM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007	LCM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007	MPM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007	PCM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007	RCM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007	RKE	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007	RVM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007	TCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	4X4	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	ABS	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	ACU	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	AFS	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	BCM/GEM	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	BSML	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	BSMR	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	EATC	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	EPS	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	FFH	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	IC	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	ICCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	LCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	MPM	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	PCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	RCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	RKE	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	RVM	✓	✓	✓	✓	○
ATENZA / MAZDA6	1.8L	L8	Other	TCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2.0L	LF	Other	4X4	✓	✓	✓	✓	○
ATENZA / MAZDA6	2.0L	LF	Other	ABS	✓	✓	✓	✓	○

ATENZA / MAZDA6	2. 0L	LF	Other	ACU	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 0L	LF	Other	AFS	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 0L	LF	Other	BCM/GEM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 0L	LF	Other	BSML	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 0L	LF	Other	BSMR	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 0L	LF	Other	EATC	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 0L	LF	Other	EPS	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 0L	LF	Other	FFH	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 0L	LF	Other	IC	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 0L	LF	Other	ICCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 0L	LF	Other	LCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 0L	LF	Other	MPM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 0L	LF	Other	PCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 0L	LF	Other	RCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 0L	LF	Other	RKE	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 0L	LF	Other	RVM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 0L	LF	Other	TCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	4X4	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	ABS	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	ACU	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	AFS	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	BCM/GEM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	BSML	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	BSMR	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	EATC	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	EPS	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	FFH	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	IC	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	ICCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	LCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	MPM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	PCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	RCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	RKE	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	RVM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 2L	R2_T	Other	TCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	4X4	✓	✓	✓	✓	○

ATENZA / MAZDA6	2. 5L	L5	Other	ABS	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	ACU	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	AFS	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	BCM/GEM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	BSML	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	BSMR	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	EATC	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	EPS	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	FFH	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	IC	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	ICCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	LCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	MPM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	PCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	RCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	RKE	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	RVM	✓	✓	✓	✓	○
ATENZA / MAZDA6	2. 5L	L5	Other	TCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	4X4	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	ABS	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	ACU	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	AFS	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	BCM/GEM	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	BSML	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	BSMR	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	EATC	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	EPS	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	FFH	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	IC	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	ICCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	LCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	MPM	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	PCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	RCM	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	RKE	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	RVM	✓	✓	✓	✓	○
ATENZA / MAZDA6	3. 7L	CA	Other	TCM	✓	✓	✓	✓	○

ATENZA AMC MZ	2. 0L	PE	Other	BSML	✓	✓	✓	✓	○
ATENZA AMC MZ	2. 0L	PE	Other	BSMR	✓	✓	✓	○	○
ATENZA AMC MZ	2. 0L	PE	Other	RVM	✓	✓	✓	○	○
ATENZA AMC MZ	2. 2L	SH	Other	BSML	✓	✓	✓	✓	○
ATENZA AMC MZ	2. 2L	SH	Other	BSMR	✓	✓	✓	○	○
ATENZA AMC MZ	2. 2L	SH	Other	RVM	✓	✓	✓	○	○
ATENZA AMC MZ	2. 5L	PY	Other	BSML	✓	✓	✓	✓	○
ATENZA AMC MZ	2. 5L	PY	Other	BSMR	✓	✓	✓	○	○
ATENZA AMC MZ	2. 5L	PY	Other	RVM	✓	✓	✓	○	○
ATENZA (JPN)/ MAZDA6 (General)	2. 0L	LF	2002 - 2005	ABS/TCS	✓	✓	✓	✓	001E
ATENZA (JPN)/ MAZDA6 (General)	2. 0L	LF	2002 - 2005	IC	✓	✓	✓	✓	○
ATENZA (JPN)/ MAZDA6 (General)	2. 0L	LF	2002 - 2005	LHID	✓	✓	✓	✓	○
ATENZA (JPN)/ MAZDA6 (General)	2. 0L	LF	2002 - 2005	PCM	✓	✓	✓	✓	0009 00C5 00C6
ATENZA (JPN)/ MAZDA6 (General)	2. 0L	LF	2002 - 2005	RCM	✓	✓	✓	✓	○
ATENZA (JPN)/ MAZDA6 (General)	2. 0L	LF	2002 - 2005	RHID	✓	✓	✓	✓	○
ATENZA (JPN)/ MAZDA6 (General)	2. 0L	LF	2005	GEM	✓	✓	✓	✓	○
ATENZA (JPN)/ MAZDA6 (General)	2. 0L	LF	2005	LCM	✓	✓	✓	✓	○
ATENZA (JPN)/ MAZDA6 (General)	2. 0L	LF	2005	RKE	✓	✓	✓	✓	○
ATENZA (JPN)/ MAZDA6 (General)	2. 0L	LF	2005	TCM	✓	✓	✓	✓	○
ATENZA (JPN)/ MAZDA6 (General)	2. 3L	L3	2002 - 2005	4X4	✓	✓	✓	✓	○
ATENZA (JPN)/ MAZDA6 (General)	2. 3L	L3	2002 - 2005	ABS/TCS	✓	✓	✓	✓	○
ATENZA (JPN)/ MAZDA6 (General)	2. 3L	L3	2002 - 2005	IC	✓	✓	✓	✓	○
ATENZA (JPN)/ MAZDA6 (General)	2. 3L	L3	2002 - 2005	LHID	✓	✓	✓	✓	○
ATENZA (JPN)/ MAZDA6 (General)	2. 3L	L3	2002 - 2005	PCM	✓	✓	✓	✓	○
ATENZA (JPN)/ MAZDA6 (General)	2. 3L	L3	2002 - 2005	RCM	✓	✓	✓	✓	○
ATENZA (JPN)/ MAZDA6 (General)	2. 3L	L3	2002 - 2005	RHID	✓	✓	✓	✓	○
ATENZA (JPN)/ MAZDA6 (General)	2. 3L	L3	2002 - 2005	TCM	✓	✓	✓	✓	○
ATENZA (JPN)/ MAZDA6 (General)	2. 3L	L3	2005	GEM	✓	✓	✓	✓	○

ATENZA (JPN) / MAZDA6 (General)	2. 3L	L3	2005	LCM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 3L	L3	2005	RKE	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 3L	L3_T	2005	4X4	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 3L	L3_T	2005	ABS/TCS	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 3L	L3_T	2005	GEM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 3L	L3_T	2005	IC	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 3L	L3_T	2005	LCM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 3L	L3_T	2005	LHID	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 3L	L3_T	2005	PCM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 3L	L3_T	2005	RCM	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 3L	L3_T	2005	RHID	✓	✓	✓	✓	○
ATENZA (JPN) / MAZDA6 (General)	2. 3L	L3_T	2005	RKE	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 5L	ZY	Other	4X4	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 5L	ZY	Other	ABS	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 5L	ZY	Other	ACU	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 5L	ZY	Other	AFS	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 5L	ZY	Other	BCM/GEM	✓	✓	✓	○	○
AXELA / MAZDA3	1. 5L	ZY	Other	BSML	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 5L	ZY	Other	BSMR	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 5L	ZY	Other	EATC	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 5L	ZY	Other	EPS	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 5L	ZY	Other	IC	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 5L	ZY	Other	LCM	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 5L	ZY	Other	MID#1	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 5L	ZY	Other	PCM	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 5L	ZY	Other	RCM	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 5L	ZY	Other	RKE	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 5L	ZY	Other	RVM	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 5L	ZY	Other	TCM	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Y6	Other	4X4	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Y6	Other	ABS	✓	✓	✓	✓	○

AXELA / MAZDA3	1. 6L	Y6	Other	ACU	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Y6	Other	AFS	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Y6	Other	BCM/GEM	✓	✓	✓	○	○
AXELA / MAZDA3	1. 6L	Y6	Other	BSML	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Y6	Other	BSMR	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Y6	Other	EATC	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Y6	Other	EPS	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Y6	Other	FACM	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Y6	Other	IC	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Y6	Other	LCM	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Y6	Other	MID#1	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Y6	Other	PCM	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Y6	Other	RCM	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Y6	Other	RKE	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Y6	Other	RVM	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Y6	Other	TCM	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Z6	Other	4X4	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Z6	Other	ABS	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Z6	Other	ACU	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Z6	Other	AFS	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Z6	Other	BCM/GEM	✓	✓	✓	○	○
AXELA / MAZDA3	1. 6L	Z6	Other	BSML	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Z6	Other	BSMR	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Z6	Other	EATC	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Z6	Other	EPS	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Z6	Other	IC	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Z6	Other	LCM	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Z6	Other	MID#1	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Z6	Other	PCM	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Z6	Other	RCM	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Z6	Other	RKE	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Z6	Other	RVM	✓	✓	✓	✓	○
AXELA / MAZDA3	1. 6L	Z6	Other	TCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	LF	Other	4X4	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	LF	Other	ABS	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	LF	Other	ACU	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	LF	Other	AFS	✓	✓	✓	✓	○

AXELA / MAZDA3	2. 0L	LF	Other	BCM/GEM	✓	✓	✓	○	○
AXELA / MAZDA3	2. 0L	LF	Other	BSML	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	LF	Other	BSMR	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	LF	Other	EATC	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	LF	Other	EPS	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	LF	Other	IC	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	LF	Other	LCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	LF	Other	MID#1	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	LF	Other	PCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	LF	Other	RCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	LF	Other	RKE	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	LF	Other	RVM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	LF	Other	TCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	PE	Other	ABS	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	PE	Other	ACU	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	PE	Other	AFS	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	PE	Other	BCM/GEM	✓	✓	✓	○	○
AXELA / MAZDA3	2. 0L	PE	Other	BSML	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	PE	Other	BSMR	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	PE	Other	EATC	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	PE	Other	EPS	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	PE	Other	IC	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	PE	Other	LCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	PE	Other	MID#1	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	PE	Other	PCM	✓	✓	✓	○	9
AXELA / MAZDA3	2. 0L	PE	Other	RCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	PE	Other	RKE	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 0L	PE	Other	RVM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 2L	R2_T	Other	4X4	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 2L	R2_T	Other	ABS	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 2L	R2_T	Other	ACU	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 2L	R2_T	Other	AFS	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 2L	R2_T	Other	BCM/GEM	✓	✓	✓	○	○
AXELA / MAZDA3	2. 2L	R2_T	Other	BSML	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 2L	R2_T	Other	BSMR	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 2L	R2_T	Other	EATC	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 2L	R2_T	Other	EPS	✓	✓	✓	✓	○

AXELA / MAZDA3	2. 2L	R2_T	Other	FFH	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 2L	R2_T	Other	IC	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 2L	R2_T	Other	LCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 2L	R2_T	Other	MID#1	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 2L	R2_T	Other	PCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 2L	R2_T	Other	RCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 2L	R2_T	Other	RKE	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 2L	R2_T	Other	RVM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 2L	R2_T	Other	TCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 3L	L3_T	Other	4X4	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 3L	L3_T	Other	ABS	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 3L	L3_T	Other	ACU	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 3L	L3_T	Other	AFS	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 3L	L3_T	Other	BCM/GEM	✓	✓	✓	○	○
AXELA / MAZDA3	2. 3L	L3_T	Other	BSML	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 3L	L3_T	Other	BSMR	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 3L	L3_T	Other	EATC	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 3L	L3_T	Other	EPS	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 3L	L3_T	Other	IC	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 3L	L3_T	Other	LCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 3L	L3_T	Other	MID#1	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 3L	L3_T	Other	PCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 3L	L3_T	Other	RCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 3L	L3_T	Other	RKE	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 3L	L3_T	Other	RVM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 3L	L3_T	Other	TCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 5L	L5	Other	4X4	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 5L	L5	Other	ABS	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 5L	L5	Other	ACU	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 5L	L5	Other	AFS	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 5L	L5	Other	BCM/GEM	✓	✓	✓	○	○
AXELA / MAZDA3	2. 5L	L5	Other	BSML	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 5L	L5	Other	BSMR	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 5L	L5	Other	EATC	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 5L	L5	Other	EPS	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 5L	L5	Other	IC	✓	✓	✓	✓	○
AXELA / MAZDA3	2. 5L	L5	Other	LCM	✓	✓	✓	✓	○

AXELA / MAZDA3	2.5L	L5	Other	MID#1	✓	✓	✓	✓	○
AXELA / MAZDA3	2.5L	L5	Other	PCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2.5L	L5	Other	RCM	✓	✓	✓	✓	○
AXELA / MAZDA3	2.5L	L5	Other	RKE	✓	✓	✓	✓	○
AXELA / MAZDA3	2.5L	L5	Other	RVM	✓	✓	✓	✓	○
AXELA / MAZDA3	2.5L	L5	Other	TCM	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 - 2006	ABS	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 - 2006	EATC	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 - 2006	EPS	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 - 2006	GEM	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 - 2006	IC	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 - 2006	PCM	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 - 2006	RCM	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2006	RKE	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 - 2006	ABS	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 - 2006	EATC	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 - 2006	EPS	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 - 2006	GEM	✓	✓	✓	✓	○

AXELA / MAZDA3 (Japan / General Specs.)	2. 0L	LF	2003 - 2006	IC	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2. 0L	LF	2003 - 2006	PCM	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2. 0L	LF	2003 - 2006	RCM	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2. 0L	LF	2006	4X4	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2. 0L	LF	2006	RKE	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2. 0L	LF	2006	TCM	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2. 3L	L3	2003 - 2006	ABS	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2. 3L	L3	2003 - 2006	EATC	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2. 3L	L3	2003 - 2006	EPS	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2. 3L	L3	2003 - 2006	GEM	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2. 3L	L3	2003 - 2006	IC	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2. 3L	L3	2003 - 2006	PCM	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2. 3L	L3	2003 - 2006	RCM	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2. 3L	L3	2006	RKE	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2. 3L	L3	2006	TCM	✓	✓	✓	✓	○

AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3_T	2006	ABS	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3_T	2006	EATC	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3_T	2006	GEM	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3_T	2006	IC	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3_T	2006	PCM	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3_T	2006	RCM	✓	✓	✓	✓	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3_T	2006	RKE	✓	✓	✓	✓	○
AZ WAGON (MD/MJ) /SPTANO (HF)	660cc	F6A-T	1998 - Other	ABS	✓	✓	✓	✓	○
AZ WAGON (MD/MJ) /SPTANO (HF)	660cc	F6A-T	1998 - Other	PCM	✓	✓	✓	✓	○
AZ WAGON (MD/MJ) /SPTANO (HF)	660cc	F6A-T	1998 - Other	RCM	✓	✓	✓	✓	○
AZ WAGON (MD/MJ) /SPTANO (HF)	660cc	K6A	1998 - 2005	ABS	✓	✓	✓	✓	○
AZ WAGON (MD/MJ) /SPTANO (HF)	660cc	K6A	1998 - 2005	PCM	✓	✓	✓	✓	○
AZ WAGON (MD/MJ) /SPTANO (HF)	660cc	K6A	1998 - 2005	RCM	✓	✓	✓	✓	○
AZ WAGON (MD/MJ) /SPTANO (HF)	660cc	K6A_T	1998	TCM	✓	✓	✓	✓	○
AZ WAGON (MD/MJ) /SPTANO (HF)	660cc	K6A_T	1998 - Other	ABS	✓	✓	✓	✓	○
AZ WAGON (MD/MJ) /SPTANO (HF)	660cc	K6A_T	1998 - Other	PCM	✓	✓	✓	✓	○
AZ WAGON (MD/MJ) /SPTANO (HF)	660cc	K6A_T	1998 - Other	RCM	✓	✓	✓	✓	○
AZ-WAGON (MT)	660cc	K6A	2003 - 2006	ABS	✓	✓	✓	✓	○
AZ-WAGON (MT)	660cc	K6A	2003 - 2006	PCM	✓	✓	✓	✓	○
AZ-WAGON (MT)	660cc	K6A	2003 - 2006	RCM	✓	✓	✓	✓	○
AZ-WAGON (MT)	660cc	K6A_T	2003 - 2005	ABS	✓	✓	✓	✓	○
AZ-WAGON (MT)	660cc	K6A_T	2003 - 2005	PCM	✓	✓	✓	✓	○

AZ-WAGON (MT)	660cc	K6A_T	2003 - 2005	RCM	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A	Other	ABS	✓	✓	✓	○	○
AZ-WAGON / CAROL	660cc	K6A	Other	BCM#1	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A	Other	EATC	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A	Other	EPS	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A	Other	PCM	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A	Other	RCM	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A	Other	TCM	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A S	Other	ABS	✓	✓	✓	○	○
AZ-WAGON / CAROL	660cc	K6A S	Other	BCM#1	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A S	Other	EATC	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A S	Other	EPS	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A S	Other	PCM	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A S	Other	RCM	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A S	Other	TCM	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A_T	Other	ABS	✓	✓	✓	○	○
AZ-WAGON / CAROL	660cc	K6A_T	Other	BCM#1	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A_T	Other	EATC	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A_T	Other	EPS	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A_T	Other	PCM	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A_T	Other	RCM	✓	✓	✓	✓	○
AZ-WAGON / CAROL	660cc	K6A_T	Other	TCM	✓	✓	✓	✓	○
AZ_OFFROAD	660cc	K6A_T	1999 - 2008	ABS	✓	✓	✓	✓	○
AZ_OFFROAD	660cc	K6A_T	1999 - 2008	PCM	✓	✓	✓	✓	○
AZ_OFFROAD	660cc	K6A_T	1999 - 2008	RCM	✓	✓	✓	✓	○
AZ_OFFROAD	660cc	K6A_T	1999 - 2008	TCM	✓	✓	✓	✓	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 2L	F2	1996 - Other	PCM	✓	✓	✓	✓	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL	2001	PCM	✓	✓	✓	✓	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL	2001 - 2002	ABS	✓	✓	✓	✓	○

B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	2001 - 2005	ABS	✓	✓	✓	✓	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	2001 - 2005	PCM	✓	✓	✓	✓	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 6L	G6	1996 - 1999	PCM	✓	✓	✓	✓	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 6L	G6	1999	ABS	✓	✓	✓	✓	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 9L	W9	2002	ABS	✓	✓	✓	✓	○
BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	1999	ABS	✓	✓	✓	✓	○
BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	1999 - 2002	PCM	✓	✓	✓	✓	○
BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	2002	ABS/TCS	✓	✓	✓	✓	○
BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	2002	TCM	✓	✓	✓	✓	○
BONGO / BONGO BRAWNY / SPECTRON	1. 8L	L8	2010	ABS	✓	✓	✓	✓	○
BONGO / BONGO BRAWNY / SPECTRON	1. 8L	L8	2010	IC	✓	✓	✓	○	○
BONGO / BONGO BRAWNY / SPECTRON	1. 8L	L8	2010	PCM	✓	✓	✓	✓	○
BONGO / BONGO BRAWNY / SPECTRON	1. 8L	L8	2010	TCM	✓	✓	✓	✓	○
BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	2003 - 2007	ABS/TCS	✓	✓	✓	✓	○
BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	2003 - 2007	PCM	✓	✓	✓	✓	○
BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	2003 - 2007	TCM	✓	✓	✓	✓	○
BONGO / BONGO BRAWNY / SPECTRON	2. 2L	R2	1999	ABS	✓	✓	✓	✓	○
BONGO / BONGO BRAWNY / SPECTRON	2. 2L	R2	1999	PCM	✓	✓	✓	✓	○

BONGO BRAWNY / ECONOVAN / MAZDA E- SERIES	1. 8L	F8	1999	ABS	✓	✓	✓	✓	○
BONGO BRAWNY / ECONOVAN / MAZDA E- SERIES	1. 8L	F8	1999	PCM	✓	✓	✓	✓	○
BONGO BRAWNY / ECONOVAN / MAZDA E- SERIES	2. 0L	FE	1997 - 1999	ABS	✓	✓	✓	✓	○
BONGO BRAWNY / ECONOVAN / MAZDA E- SERIES	2. 0L	FE	1997 - 2002	PCM	✓	✓	✓	✓	○
BONGO BRAWNY / ECONOVAN / MAZDA E- SERIES	2. 0L	FE	2002	ABS/TCS	✓	✓	✓	✓	○
BONGO BRAWNY / ECONOVAN / MAZDA E- SERIES	2. 0L	FE	2002	TCM	✓	✓	✓	✓	○
BONGO BRAWNY / ECONOVAN / MAZDA E- SERIES	2. 2L	R2	1999	ABS	✓	✓	✓	✓	○
BONGO BRAWNY / ECONOVAN / MAZDA E- SERIES	2. 2L	R2	1999	PCM	✓	✓	✓	✓	○
BONGO BRAWNY / ECONOVAN / MAZDA E- SERIES	2. 5L	WL	1999	ABS	✓	✓	✓	✓	○
BONGO BRAWNY / ECONOVAN / MAZDA E- SERIES	2. 5L	WL	1999	PCM	✓	✓	✓	✓	○
BT-50 / Ranger	2. 2L	F2	2007	ABS/TCS	✓	✓	✓	✓	○
BT-50 / Ranger	2. 2L	F2	2007	PCM	✓	✓	✓	✓	○
BT-50 / Ranger	2. 2L	F2	2007	RCM	✓	✓	✓	✓	○
BT-50 / Ranger	2. 5L	L5	2012	ABS	✓	✓	✓	✓	○
BT-50 / Ranger	2. 5L	L5	2012	PCM	✓	✓	✓	○	○
BT-50 / Ranger	2. 5L	WL	2007	ABS/TCS	✓	✓	✓	✓	○
BT-50 / Ranger	2. 5L	WL	2007	PCM	✓	✓	✓	✓	○
BT-50 / Ranger	2. 5L	WL	2007	RCM	✓	✓	✓	✓	○
BT-50 / Ranger	2. 5L	WL-CD	2007	ABS/TCS	✓	✓	✓	✓	○
BT-50 / Ranger	2. 5L	WL-CD	2007	PCM	✓	✓	✓	✓	○
BT-50 / Ranger	2. 5L	WL-CD	2007	RCM	✓	✓	✓	✓	○
BT-50 / Ranger	2. 5L	WL-CD	2007	TCM	✓	✓	✓	✓	○
BT-50 / Ranger	2. 6L	G6	2007	ABS/TCS	✓	✓	✓	✓	○
BT-50 / Ranger	2. 6L	G6	2007	PCM	✓	✓	✓	✓	○
BT-50 / Ranger	2. 6L	G6	2007	RCM	✓	✓	✓	✓	○
BT-50 / Ranger	3. 0L	WE-CD	2007	ABS/TCS	✓	✓	✓	✓	○
BT-50 / Ranger	3. 0L	WE-CD	2007	PCM	✓	✓	✓	✓	○

BT-50 / Ranger	3. 0L	WE-CD	2007	RCM	✓	✓	✓	✓	○
BT-50 / Ranger	3. 0L	WE-CD	2007	TCM	✓	✓	✓	✓	○
BT-50 / Ranger	4. 0L	V6 SOHC	2007	ABS/TCS	✓	✓	✓	✓	8
BT-50 / Ranger	4. 0L	V6 SOHC	2007	ESOF	✓	✓	✓	✓	○
BT-50 / Ranger	4. 0L	V6 SOHC	2007	PCM	✓	✓	✓	✓	23
BT-50 / Ranger	4. 0L	V6 SOHC	2007	RCM	✓	✓	✓	✓	○
Biante(Japan)	2. 0L	LF	2008	4X4	✓	✓	✓	✓	○
Biante(Japan)	2. 0L	LF	2008	ABS	✓	✓	✓	✓	○
Biante(Japan)	2. 0L	LF	2008	EATC	✓	✓	✓	✓	○
Biante(Japan)	2. 0L	LF	2008	EPS	✓	✓	✓	✓	○
Biante(Japan)	2. 0L	LF	2008	GEM	✓	✓	✓	✓	○
Biante(Japan)	2. 0L	LF	2008	IC	✓	✓	✓	✓	○
Biante(Japan)	2. 0L	LF	2008	LPSDM	✓	✓	✓	✓	○
Biante(Japan)	2. 0L	LF	2008	PCM	✓	✓	✓	✓	○
Biante(Japan)	2. 0L	LF	2008	RCM	✓	✓	✓	✓	○
Biante(Japan)	2. 0L	LF	2008	RKE	✓	✓	✓	✓	○
Biante(Japan)	2. 0L	LF	2008	RPSDM	✓	✓	✓	✓	○
Biante(Japan)	2. 0L	LF	2008	TCM	✓	✓	✓	○	○
Biante(Japan)	2. 3L	L3	2008	ABS	✓	✓	✓	✓	○
Biante(Japan)	2. 3L	L3	2008	EATC	✓	✓	✓	✓	○
Biante(Japan)	2. 3L	L3	2008	EPS	✓	✓	✓	✓	○
Biante(Japan)	2. 3L	L3	2008	GEM	✓	✓	✓	✓	○
Biante(Japan)	2. 3L	L3	2008	IC	✓	✓	✓	✓	○
Biante(Japan)	2. 3L	L3	2008	LPSDM	✓	✓	✓	✓	○
Biante(Japan)	2. 3L	L3	2008	PCM	✓	✓	✓	✓	○
Biante(Japan)	2. 3L	L3	2008	RCM	✓	✓	✓	✓	○
Biante(Japan)	2. 3L	L3	2008	RKE	✓	✓	✓	✓	○
Biante(Japan)	2. 3L	L3	2008	RPSDM	✓	✓	✓	✓	○
Biante(Japan)	2. 3L	L3	2008	TCM	✓	✓	✓	○	○
CAPELLA / CAPELLA_W / TELSTAR / TELSTAR_W	1. 8L	FP	1997 - 1999	PCM	✓	✓	✓	✓	○
CAPELLA / CAPELLA_W / TELSTAR / TELSTAR_W	1. 8L	FP	1999	ABS	✓	✓	✓	✓	○
CAPELLA / CAPELLA_W / TELSTAR / TELSTAR_W	2. 0L	FS	1997 - 1999	PCM	✓	✓	✓	✓	○
CAPELLA / CAPELLA_W / TELSTAR / TELSTAR_W	2. 0L	FS	1999	ABS	✓	✓	✓	✓	○

CAPELLA / CAPELLA_W / TELSTAR / TELSTAR_W	2. 0L	RF	1997	PCM	✓	✓	✓	✓	○
CAPELLA / CAPELLA_W / TELSTAR / TELSTAR_W	2. 5L	KL	1999	ABS	✓	✓	✓	✓	○
CAROL	660cc	F6A	1998 - Other	ABS	✓	✓	✓	✓	○
CAROL	660cc	F6A	1998 - Other	PCM	✓	✓	✓	✓	○
CAROL	660cc	F6A	1998 - Other	RCM	✓	✓	✓	✓	○
CAROL	660cc	K6A	1998 - Other	ABS	✓	✓	✓	✓	○
CAROL	660cc	K6A	1998 - Other	PCM	✓	✓	✓	✓	○
CAROL	660cc	K6A	1998 - Other	RCM	✓	✓	✓	✓	○
CAROL	660cc	K6A	1998 - Other	TCM	✓	✓	✓	✓	○
CAROL (2003 / 9 -)	660cc	K6A	2003 - 2004	PCM	✓	✓	✓	✓	○
CAROL (2003 / 9 -)	660cc	K6A	2003 - Other	ABS	✓	✓	✓	✓	○
CAROL (2003 / 9 -)	660cc	K6A	2003 - Other	RCM	✓	✓	✓	✓	○
CAROL (HB24S)	660cc	K6A	2004 - 2005	ABS	✓	✓	✓	✓	○
CAROL (HB24S)	660cc	K6A	2004 - 2005	PCM	✓	✓	✓	✓	○
CAROL (HB24S)	660cc	K6A	2004 - 2005	RCM	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 2L	R2_T	2009	4X4	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 2L	R2_T	2009	ABS	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 2L	R2_T	2009	ACU	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 2L	R2_T	2009	AM	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 2L	R2_T	2009	EATC	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 2L	R2_T	2009	EPS	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 2L	R2_T	2009	FFH	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 2L	R2_T	2009	GEM	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 2L	R2_T	2009	IC	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 2L	R2_T	2009	LCM	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 2L	R2_T	2009	MID#1	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 2L	R2_T	2009	PCM	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 2L	R2_T	2009	RCM	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 2L	R2_T	2009	RKE	✓	✓	✓	✓	○

CX-7 (Europe / General Specs.)	2. 2L	R2_T	2009	RVM	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 2L	R2_T	2009	SCR CU	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 3L	L3_T	2006 - 2009	4X4	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 3L	L3_T	2006 - 2009	ABS	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 3L	L3_T	2006 - 2009	AM	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 3L	L3_T	2006 - 2009	EATC	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 3L	L3_T	2006 - 2009	GEM	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 3L	L3_T	2006 - 2009	IC	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 3L	L3_T	2006 - 2009	LCM	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 3L	L3_T	2006 - 2009	PCM	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 3L	L3_T	2006 - 2009	RCM	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 3L	L3_T	2006 - 2009	RKE	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 3L	L3_T	2006 - 2009	TCM	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 3L	L3_T	2009	ACU	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 3L	L3_T	2009	MID#1	✓	✓	✓	✓	○
CX-7 (Europe / General Specs.)	2. 3L	L3_T	2009	RVM	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 3L	L3_T	2006 - 2009	4X4	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 3L	L3_T	2006 - 2009	ABS	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 3L	L3_T	2006 - 2009	AM	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 3L	L3_T	2006 - 2009	EATC	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 3L	L3_T	2006 - 2009	GEM	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 3L	L3_T	2006 - 2009	IC	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 3L	L3_T	2006 - 2009	ICCM	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 3L	L3_T	2006 - 2009	LCM	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 3L	L3_T	2006 - 2009	PCM	✓	✓	✓	✓	○

CX-7 (Japan / General Specs.)	2. 3L	L3_T	2006 - 2009	RCM	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 3L	L3_T	2006 - 2009	RKE	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 3L	L3_T	2006 - 2009	TCM	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 3L	L3_T	2009	ACU	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 3L	L3_T	2009	MID#1	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 3L	L3_T	2009	RVM	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 5L	L5	2009	4X4	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 5L	L5	2009	ABS	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 5L	L5	2009	ACU	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 5L	L5	2009	AM	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 5L	L5	2009	EATC	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 5L	L5	2009	GEM	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 5L	L5	2009	IC	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 5L	L5	2009	ICCM	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 5L	L5	2009	LCM	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 5L	L5	2009	MID#1	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 5L	L5	2009	PCM	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 5L	L5	2009	RCM	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 5L	L5	2009	RKE	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 5L	L5	2009	RVM	✓	✓	✓	✓	○
CX-7 (Japan / General Specs.)	2. 5L	L5	2009	TCM	✓	✓	✓	✓	○
CX-7 (North America / General Specs.)	2. 3L	L3_T	2007 - 2010	4X4	✓	✓	✓	✓	○
CX-7 (North America / General Specs.)	2. 3L	L3_T	2007 - 2010	ABS	✓	✓	✓	✓	○
CX-7 (North America / General Specs.)	2. 3L	L3_T	2007 - 2010	AM	✓	✓	✓	✓	○

CX-7 (North America / General Specs)	2. 3L	L3_T	2007 - 2010	EATC	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 3L	L3_T	2007 - 2010	GEM	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 3L	L3_T	2007 - 2010	IC	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 3L	L3_T	2007 - 2010	PCM	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 3L	L3_T	2007 - 2010	RCM	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 3L	L3_T	2007 - 2010	RKE	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 3L	L3_T	2007 - 2010	TCM	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 3L	L3_T	2010	ACU	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 3L	L3_T	2010	BSML	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 3L	L3_T	2010	BSMR	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 3L	L3_T	2010	LCM	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 3L	L3_T	2010	MID#1	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 5L	L5	2010	4X4	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 5L	L5	2010	ABS	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 5L	L5	2010	ACU	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 5L	L5	2010	AM	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 5L	L5	2010	BSML	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2. 5L	L5	2010	BSMR	✓	✓	✓	✓	○

CX-7 (North America / General Specs)	2.5L	L5	2010	EATC	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2.5L	L5	2010	GEM	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2.5L	L5	2010	IC	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2.5L	L5	2010	LCM	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2.5L	L5	2010	MID#1	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2.5L	L5	2010	PCM	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2.5L	L5	2010	RCM	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2.5L	L5	2010	RKE	✓	✓	✓	✓	○
CX-7 (North America / General Specs)	2.5L	L5	2010	TCM	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3.5L	CY	2007 - Other	4X4	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3.5L	CY	2007 - Other	ABS	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3.5L	CY	2007 - Other	AM	✓	✓	✓	✓	5
CX-9 (North America / General Specs)	3.5L	CY	2007 - Other	GEM	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3.5L	CY	2007 - Other	IC	✓	✓	✓	✓	0005 001A
CX-9 (North America / General Specs)	3.5L	CY	2007 - Other	LCM	✓	✓	○	○	○
CX-9 (North America / General Specs)	3.5L	CY	2007 - Other	LTM	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3.5L	CY	2007 - Other	PCM	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3.5L	CY	2007 - Other	RCM	✓	✓	✓	✓	5

CX-9 (North America / General Specs)	3. 5L	CY	2007 - Other	RKE	✓	✓	✓	✓	5
CX-9 (North America / General Specs)	3. 5L	CY	2007 - Other	TCM	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3. 7L	CA	2008 - 2011	4X4	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3. 7L	CA	2008 - 2011	ABS	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3. 7L	CA	2008 - 2011	AM	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3. 7L	CA	2008 - 2011	BSML	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3. 7L	CA	2008 - 2011	BSMR	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3. 7L	CA	2008 - 2011	GEM	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3. 7L	CA	2008 - 2011	IC	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3. 7L	CA	2008 - 2011	LCM	✓	✓	○	○	○
CX-9 (North America / General Specs)	3. 7L	CA	2008 - 2011	LTM	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3. 7L	CA	2008 - 2011	PCM	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3. 7L	CA	2008 - 2011	RCM	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3. 7L	CA	2008 - 2011	RKE	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3. 7L	CA	2008 - 2011	TCM	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3. 7L	CA	2010 - 2011	ACU	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3. 7L	CA	2010 - 2011	DSM	✓	✓	✓	✓	○
CX-9 (North America / General Specs)	3. 7L	CA	2011	VSM	✓	✓	✓	○	○
CX_7	2. 0L	PE	Other	BSML	✓	✓	✓	✓	○
CX_7	2. 0L	PE	Other	BSMR	✓	✓	✓	○	○

CX_7	2. 0L	PE	Other	RVM	✓	✓	✓	○	○
CX_7	2. 2L	SH	Other	BSML	✓	✓	✓	✓	○
CX_7	2. 2L	SH	Other	BSMR	✓	✓	✓	○	○
CX_7	2. 2L	SH	Other	RVM	✓	✓	✓	○	○
CX_7	2. 5L	PY	Other	BSML	✓	✓	✓	✓	○
CX_7	2. 5L	PY	Other	BSMR	✓	✓	✓	○	○
CX_7	2. 5L	PY	Other	RVM	✓	✓	✓	○	○
DEMIO (JPN) / MAZDA2 (General)	1. 3L	ZJ	2007	4X4	✓	✓	✓	✓	○
DEMIO (JPN) / MAZDA2 (General)	1. 3L	ZJ	2007	ABS	✓	✓	✓	✓	○
DEMIO (JPN) / MAZDA2 (General)	1. 3L	ZJ	2007	BCM/GEM	✓	✓	✓	✓	○
DEMIO (JPN) / MAZDA2 (General)	1. 3L	ZJ	2007	EPS	✓	✓	✓	✓	○
DEMIO (JPN) / MAZDA2 (General)	1. 3L	ZJ	2007	IC	✓	✓	✓	✓	○
DEMIO (JPN) / MAZDA2 (General)	1. 3L	ZJ	2007	PCM	✓	✓	✓	✓	○
DEMIO (JPN) / MAZDA2 (General)	1. 3L	ZJ	2007	RCM	✓	✓	✓	✓	○
DEMIO (JPN) / MAZDA2 (General)	1. 3L	ZJ	2007	RKE	✓	✓	✓	✓	○
DEMIO (JPN) / MAZDA2 (General)	1. 3L	ZJ	2007	TCM	✓	✓	✓	✓	○
DEMIO (JPN) / MAZDA2 (General)	1. 5L	ZY	2007	ABS	✓	✓	✓	✓	○
DEMIO (JPN) / MAZDA2 (General)	1. 5L	ZY	2007	BCM/GEM	✓	✓	✓	✓	○
DEMIO (JPN) / MAZDA2 (General)	1. 5L	ZY	2007	EPS	✓	✓	✓	✓	○
DEMIO (JPN) / MAZDA2 (General)	1. 5L	ZY	2007	IC	✓	✓	✓	✓	○
DEMIO (JPN) / MAZDA2 (General)	1. 5L	ZY	2007	PCM	✓	✓	✓	✓	○
DEMIO (JPN) / MAZDA2 (General)	1. 5L	ZY	2007	RCM	✓	✓	✓	✓	○
DEMIO (JPN) / MAZDA2 (General)	1. 5L	ZY	2007	RKE	✓	✓	✓	✓	○
DEMIO (JPN) / MAZDA2 (General)	1. 5L	ZY	2007	TCM	✓	✓	✓	✓	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2002 - 2005	PCM	✓	✓	✓	✓	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2002 - Other	4X4	✓	✓	✓	✓	○

DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2002 - Other	ABS/TCS	✓	✓	✓	✓	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2002 - Other	IC	✓	✓	✓	✓	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2002 - Other	RCM	✓	✓	✓	✓	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2002 - Other	RKE	✓	✓	✓	✓	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2005	EPS	✓	✓	✓	✓	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2005	LCM	✓	✓	✓	✓	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 5L	ZY	2002 - 2005	PCM	✓	✓	✓	✓	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 5L	ZY	2002 - Other	4X4	✓	✓	✓	✓	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 5L	ZY	2002 - Other	ABS/TCS	✓	✓	✓	✓	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 5L	ZY	2002 - Other	IC	✓	✓	✓	✓	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 5L	ZY	2002 - Other	RCM	✓	✓	✓	✓	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 5L	ZY	2002 - Other	RKE	✓	✓	✓	✓	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 5L	ZY	2005	EPS	✓	✓	✓	✓	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 5L	ZY	2005	LCM	✓	✓	✓	✓	○
DEMIO / 121_DEMIO / 121	1. 3L	B3	1996 - 2000	ABS	✓	✓	✓	✓	○

DEMIO / 121_DEMIO / 121	1. 3L	B3	1996 - 2000	PCM	✓	✓	✓	✓	○
DEMIO / 121_DEMIO / 121	1. 3L	B3	2000	ABS/TCS	✓	✓	✓	✓	○
DEMIO / 121_DEMIO / 121	1. 5L	B5	1996 - 2000	ABS	✓	✓	✓	✓	○
DEMIO / 121_DEMIO / 121	1. 5L	B5	2000	ABS/TCS	✓	✓	✓	✓	○
DEMIO / 121_DEMIO / 121	1. 5L	B5	2000	PCM	✓	✓	✓	✓	○
DEMIO / FESTIVA MINI WAGON	1. 3L	B3	1996 - 1999	ABS	✓	✓	✓	✓	○
DEMIO / FESTIVA MINI WAGON	1. 3L	B3	1996 - Other	PCM	✓	✓	✓	✓	○
DEMIO / FESTIVA MINI WAGON	1. 3L	B3	2000	ABS/TCS	✓	✓	✓	✓	○
DEMIO / FESTIVA MINI WAGON	1. 5L	B5	1996 - 1999	ABS	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	P3	Other	4X4	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	P3	Other	ABS	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	P3	Other	BCM/GEM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	P3	Other	EATC	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	P3	Other	EPS	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	P3	Other	IC	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	P3	Other	PCM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	P3	Other	RCM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	P3	Other	RKE	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	P3	Other	TCM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	P3	Other	VSM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	ZJ	Other	4X4	✓	✓	✓	✓	○

DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	ZJ	Other	ABS	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	ZJ	Other	BCM/GEM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	ZJ	Other	EATC	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	ZJ	Other	EPS	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	ZJ	Other	IC	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	ZJ	Other	PCM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	ZJ	Other	RCM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	ZJ	Other	RKE	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	ZJ	Other	TCM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 3L	ZJ	Other	VSM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 5L	ZY	Other	4X4	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 5L	ZY	Other	ABS	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 5L	ZY	Other	BCM/GEM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 5L	ZY	Other	EATC	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 5L	ZY	Other	EPS	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 5L	ZY	Other	IC	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 5L	ZY	Other	PCM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1. 5L	ZY	Other	RCM	✓	✓	✓	✓	○

DEMIO_(JPN) / MAZDA2_(OTHE R)	1.5L	ZY	Other	RKE	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1.5L	ZY	Other	TCM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1.5L	ZY	Other	VSM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1.6L	Y6	Other	4X4	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1.6L	Y6	Other	ABS	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1.6L	Y6	Other	BCM/GEM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1.6L	Y6	Other	EATC	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1.6L	Y6	Other	EPS	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1.6L	Y6	Other	IC	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1.6L	Y6	Other	PCM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1.6L	Y6	Other	RCM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1.6L	Y6	Other	RKE	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1.6L	Y6	Other	TCM	✓	✓	✓	✓	○
DEMIO_(JPN) / MAZDA2_(OTHE R)	1.6L	Y6	Other	VSM	✓	✓	✓	✓	○
Escape / Tribute (2006/4 -)	2.3L	L3	2006	ABS	✓	✓	✓	✓	○
Escape / Tribute (2006/4 -)	2.3L	L3	2006	GEM	✓	✓	✓	✓	○
Escape / Tribute (2006/4 -)	2.3L	L3	2006	IC	✓	✓	✓	✓	○
Escape / Tribute (2006/4 -)	2.3L	L3	2006	PCM	✓	✓	✓	✓	○
Escape / Tribute (2006/4 -)	2.3L	L3	2006	RCM	✓	✓	✓	✓	○
Escape / Tribute (2006/3)	2.3L	L3	2003	ABS	✓	✓	✓	✓	○

Escape / Tribute (2006/3)	2. 3L	L3	2003	GEM	✓	✓	✓	✓	○
Escape / Tribute (2006/3)	2. 3L	L3	2003	IC	✓	✓	✓	✓	○
Escape / Tribute (2006/3)	2. 3L	L3	2003	PCM	✓	✓	✓	✓	○
Escape / Tribute (2006/3)	2. 3L	L3	2003	RCM	✓	✓	✓	✓	○
Escape / Tribute / Maverick	2. 0L	Zetec	2001 - 2004	ABS/TCS	✓	✓	✓	✓	8
Escape / Tribute / Maverick	2. 0L	Zetec	2001 - 2004	GEM	✓	✓	✓	✓	000A
Escape / Tribute / Maverick	2. 0L	Zetec	2001 - 2004	IC	✓	✓	✓	✓	○
Escape / Tribute / Maverick	2. 0L	Zetec	2001 - 2004	PCM	✓	✓	✓	✓	0009 0010 0023 0025 0028 0031 0033
Escape / Tribute / Maverick	2. 0L	Zetec	2001 - 2004	RCM	✓	✓	✓	✓	○
Escape / Tribute / Maverick	2. 0L	Zetec	2003 - 2004	PAM	✓	✓	✓	✓	○
Escape / Tribute / Maverick	2. 3L	DURATEC-HE / I4	2006 - 2007	4X4	✓	✓	✓	✓	○
Escape / Tribute / Maverick	2. 3L	DURATEC-HE / I4	2006 - 2007	ABS	✓	✓	✓	✓	8
Escape / Tribute / Maverick	2. 3L	DURATEC-HE / I4	2006 - 2007	GEM	✓	✓	✓	✓	000A 000F
Escape / Tribute / Maverick	2. 3L	DURATEC-HE / I4	2006 - 2007	IC	✓	✓	✓	✓	○
Escape / Tribute / Maverick	2. 3L	DURATEC-HE / I4	2006 - 2007	PAM	✓	✓	✓	✓	○
Escape / Tribute / Maverick	2. 3L	DURATEC-HE / I4	2006 - 2007	PCM	✓	✓	✓	✓	0009 0010 0023 0025 0028 0031 0033 00C5
Escape / Tribute / Maverick	2. 3L	DURATEC-HE / I4	2006 - 2007	RCM	✓	✓	✓	✓	000C
Escape / Tribute / Maverick	3. 0L	4V	2001 - 2004	ABS/TCS	✓	✓	✓	✓	8
Escape / Tribute / Maverick	3. 0L	4V	2001 - 2007	GEM	✓	✓	✓	✓	000A 000F
Escape / Tribute / Maverick	3. 0L	4V	2001 - 2007	IC	✓	✓	✓	✓	5
Escape / Tribute / Maverick	3. 0L	4V	2001 - 2007	PCM	✓	✓	✓	✓	0009 0010 0023 0025 0028 0031 0033 00C5
Escape / Tribute / Maverick	3. 0L	4V	2001 - 2007	RCM	✓	✓	✓	✓	000C
Escape / Tribute / Maverick	3. 0L	4V	2003 - 2007	PAM	✓	✓	✓	✓	○
Escape / Tribute / Maverick	3. 0L	4V	2006 - 2007	4X4	✓	✓	✓	✓	○

Escape / Tribute / Maverick	3. 0L	4V	2006 - 2007	ABS	✓	✓	✓	✓	0005 0008
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	✓	✓	✓	✓	12
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	APIM	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	DDM	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSM	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSP	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCIM	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPSM	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	HCM	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	HVAC	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-B	✓	✓	✓	○	○

Escape/Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	2013	OCSM	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	2013	PAM	✓	✓	○	○	○
Escape/Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	2013	PCM	✓	✓	✓	✓	0023 0025
Escape/Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	2013	PDM	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	2013	PSCM	✓	✓	✓	○	00CB 00CC
Escape/Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	2013	RCM	✓	✓	✓	○	○
Escape/Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	2013	RFA	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	2013	RGTM	✓	✓	✓	○	○
Escape/Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	2013	SASM	✓	✓	✓	○	○
Escape/Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	2013	SOD-L	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	2013	SOD-R	✓	✓	✓	✓	○
Escape/Kuga	1. 6L	EcoBoost – Gas Turbocharged Direct Injection	2013	TRM	✓	✓	✓	✓	○
Escape/Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	2013	ABS	✓	✓	✓	✓	12
Escape/Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	2013	ACM	✓	✓	✓	✓	○
Escape/Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	2013	APIM	✓	✓	✓	✓	○

Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2013	BCM#1	✓	✓	✓	✓	○
Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2013	DDM	✓	✓	✓	✓	○
Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2013	DSM	✓	✓	✓	✓	○
Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2013	DSP	✓	✓	✓	✓	○
Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2013	FCDIM	✓	✓	✓	✓	○
Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2013	FCIM	✓	✓	✓	✓	○
Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2013	GPSM	✓	✓	✓	✓	○
Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2013	HCM	✓	✓	✓	✓	○
Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2013	HVAC	✓	✓	✓	✓	○
Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2013	IPC	✓	✓	✓	✓	○
Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2013	IPM-B	✓	✓	✓	○	○
Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2013	OCSM	✓	✓	✓	✓	○
Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2013	PAM	✓	✓	○	○	○
Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2013	PCM	✓	✓	✓	✓	0023 0025
Escape/Kuga	2.0L	EcoBoost – Gas Turbocharged Direct Injection	2013	PDM	✓	✓	✓	✓	○

Escape/Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	2013	PSCM	✓	✓	✓	○	00CB 00CC
Escape/Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	2013	RCM	✓	✓	✓	○	○
Escape/Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	2013	RFA	✓	✓	✓	✓	○
Escape/Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	2013	RGTM	✓	✓	✓	○	○
Escape/Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	2013	SASM	✓	✓	✓	○	○
Escape/Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	2013	SOD-L	✓	✓	✓	✓	○
Escape/Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	2013	SOD-R	✓	✓	✓	✓	○
Escape/Kuga	2. 0L	EcoBoost – Gas Turbocharged Direct Injection	2013	TRM	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	ABS	✓	✓	✓	✓	12
Escape/Kuga	2. 5L	IVCT	2013	ACM	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	APIM	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	BCM#1	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	DDM	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	DSM	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	DSP	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	FCDIM	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	FCIM	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	GPSM	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	HCM	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	HVAC	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	IPC	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	IPM-B	✓	✓	✓	○	○
Escape/Kuga	2. 5L	IVCT	2013	OCSM	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	PAM	✓	✓	○	○	○
Escape/Kuga	2. 5L	IVCT	2013	PCM	✓	✓	✓	✓	0023 0025
Escape/Kuga	2. 5L	IVCT	2013	PDM	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	PSCM	✓	✓	✓	○	00CB 00CC
Escape/Kuga	2. 5L	IVCT	2013	RCM	✓	✓	✓	○	○
Escape/Kuga	2. 5L	IVCT	2013	RFA	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	RGTM	✓	✓	✓	○	○

Escape/Kuga	2. 5L	IVCT	2013	SASM	✓	✓	✓	○	○
Escape/Kuga	2. 5L	IVCT	2013	SOD-L	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	SOD-R	✓	✓	✓	✓	○
Escape/Kuga	2. 5L	IVCT	2013	TRM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	4X4	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	ABS	✓	✓	✓	✓	0005 0008 0012
Escape/Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	ACM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	FCIM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	FDIM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	GEM / SJB	✓	✓	✓	✓	000A 000F 0042
Escape/Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	HVAC	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	IC	✓	✓	✓	✓	0005 0009
Escape/Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	OCSM	✓	✓	✓	○	000C
Escape/Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	PAM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	PCM	✓	✓	✓	✓	0010 0023 0025 0028 0031 0033
Escape/Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	PSCM	✓	✓	○	○	0005 0053
Escape/Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	RCM	✓	✓	✓	✓	5
Escape/Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	SDARS	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	4X4	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	ABS	✓	✓	✓	✓	0005 0012
Escape/Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	ACM	✓	✓	✓	✓	5
Escape/Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	BCM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	FCIM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	FDIM	✓	✓	✓	✓	5
Escape/Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	GEM / SJB	✓	✓	✓	✓	000A 000F 0042
Escape/Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	HVAC	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	IC	✓	✓	✓	✓	0005 0009

Escape/Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	OCSM	✓	✓	✓	○	000C
Escape/Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	PAM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	PCM	✓	✓	✓	✓	0010 0023 0025 0028 0031 0033 00C5
Escape/Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	PSCM	✓	✓	○	○	0005 0053
Escape/Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	RCM	✓	✓	✓	✓	5
Escape/Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	SDARS	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	TCM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009	SDARS	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	4X4	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	ABS	✓	✓	✓	✓	12
Escape/Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	ACM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	APIM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	FCIM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	FDIM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	GEM / SJB	✓	✓	✓	✓	000A 000F 0042
Escape/Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	HVAC	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	IC	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	OCSM	✓	✓	✓	○	000C
Escape/Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	PAM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	PCM	✓	✓	✓	✓	25
Escape/Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	PSCM	✓	✓	○	○	○
Escape/Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	RCM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2. 5L	DURATEC-HE / I4	2010 - 2012	GPSM	✓	✓	✓	○	○
Escape/Tribute / Mariner	2. 5L	HEV / ATKINSON 4V	2009	SDARS	✓	✓	✓	✓	○

Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	4X4	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	ABS	✓	✓	✓	✓	5
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	ACM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	APIM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	BCM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	FCIM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	FDIM	✓	✓	✓	✓	5
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	GEM / SJB	✓	✓	✓	✓	000A 000F 0042
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	HVAC	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	IC	✓	✓	✓	✓	0009 0005
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	OCSM	✓	✓	✓	○	000C
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	PAM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	PCM	✓	✓	✓	✓	0023 0025 0010 0028 0031 0033
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	PSCM	✓	✓	○	○	0053 0005 00CC
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	RCM	✓	✓	✓	✓	5
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	TCM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 - 2012	ACCM#2	✓	✓	✓	✓	○
Escape/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 - 2012	GPSM	✓	✓	✓	○	○
Escape/Tribute / Mariner	3.0L	4V	2008 - 2009	SDARS	✓	✓	✓	✓	0005 0019
Escape/Tribute / Mariner	3.0L	4V	2008 - 2012	4X4	✓	✓	✓	✓	○
Escape/Tribute / Mariner	3.0L	4V	2008 - 2012	ABS	✓	✓	✓	✓	0005 0008 0012
Escape/Tribute / Mariner	3.0L	4V	2008 - 2012	ACM	✓	✓	✓	✓	0017 0018
Escape/Tribute / Mariner	3.0L	4V	2008 - 2012	FCIM	✓	✓	✓	✓	○
Escape/Tribute / Mariner	3.0L	4V	2008 - 2012	FDIM	✓	✓	✓	✓	5
Escape/Tribute / Mariner	3.0L	4V	2008 - 2012	GEM / SJB	✓	✓	✓	✓	000A 000F 0042

Escape_/Tribute / Mariner	3. 0L	4V	2008 - 2012	HVAC	✓	✓	✓	✓	5
Escape_/Tribute / Mariner	3. 0L	4V	2008 - 2012	IC	✓	✓	✓	✓	0009 0005
Escape_/Tribute / Mariner	3. 0L	4V	2008 - 2012	OCSM	✓	✓	✓	○	000C
Escape_/Tribute / Mariner	3. 0L	4V	2008 - 2012	PAM	✓	✓	✓	✓	○
Escape_/Tribute / Mariner	3. 0L	4V	2008 - 2012	PCM	✓	✓	✓	✓	0010 0023 0025 0028 0031 0033 0009 00C5
Escape_/Tribute / Mariner	3. 0L	4V	2008 - 2012	PSCM	✓	✓	○	○	0005 0053
Escape_/Tribute / Mariner	3. 0L	4V	2008 - 2012	RCM	✓	✓	✓	✓	5
Escape_/Tribute / Mariner	3. 0L	4V	2009 - 2012	APIM	✓	✓	✓	✓	001C
Escape_/Tribute / Mariner	3. 0L	4V	2010 - 2012	GPSM	✓	✓	✓	○	○
Escape_/Tribute / Mariner	Other	Other	2012	4X4	✓	✓	✓	✓	○
Escape_/Tribute / Mariner	Other	Other	2012	ABS	✓	✓	✓	✓	○
Escape_/Tribute / Mariner	Other	Other	2012	ACM	✓	✓	✓	○	○
Escape_/Tribute / Mariner	Other	Other	2012	APIM	✓	✓	✓	○	○
Escape_/Tribute / Mariner	Other	Other	2012	FCIM	✓	✓	✓	✓	○
Escape_/Tribute / Mariner	Other	Other	2012	FDIM	✓	✓	✓	✓	○
Escape_/Tribute / Mariner	Other	Other	2012	GEM / SJB	✓	✓	✓	✓	42
Escape_/Tribute / Mariner	Other	Other	2012	GPSM	✓	✓	✓	✓	○
Escape_/Tribute / Mariner	Other	Other	2012	HVAC	✓	✓	✓	✓	○
Escape_/Tribute / Mariner	Other	Other	2012	IC	✓	✓	✓	✓	○
Escape_/Tribute / Mariner	Other	Other	2012	OCSM	✓	✓	✓	○	○
Escape_/Tribute / Mariner	Other	Other	2012	PAM	✓	✓	✓	○	○
Escape_/Tribute / Mariner	Other	Other	2012	PSCM	✓	✓	○	○	○
Escape_/Tribute / Mariner	Other	Other	2012	RCM	✓	✓	✓	✓	○
FAMILIA / LASER	1. 3L	B3	1998	ABS	✓	✓	✓	✓	○
FAMILIA / LASER	1. 3L	B3	1998	PCM	✓	✓	✓	✓	○

FAMILIA / LASER	1. 5L	ZL	1998 - 2000	ABS	✓	✓	✓	✓	○
FAMILIA / LASER	1. 5L	ZL	1998 - 2002	PCM	✓	✓	✓	✓	○
FAMILIA / LASER	1. 5L	ZL	2000 - 2002	ABS/TCS	✓	✓	✓	✓	○
FAMILIA / LASER	1. 8L	FP	1998	ABS	✓	✓	✓	✓	○
FAMILIA / LASER	1. 8L	FP	1998	PCM	✓	✓	✓	✓	○
FAMILIA / LASER	2. 0L	FS	1999 - 2000	ABS	✓	✓	✓	✓	○
FAMILIA / LASER	2. 0L	FS	1999 - 2002	PCM	✓	✓	✓	✓	○
FAMILIA / LASER	2. 0L	FS	2002	ABS/TCS	✓	✓	✓	✓	○
FAMILIA / LASER	2. 0L	RF	1998	ABS	✓	✓	✓	✓	○
FAMILIA / LASER	2. 0L	RF	1998	PCM	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 2L	CR12	2007	ABS	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 2L	CR12	2007	EPS	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 2L	CR12	2007	GEM	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 2L	CR12	2007	IC	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 2L	CR12	2007	IPDM	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 2L	CR12	2007	PCM	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 2L	CR12	2007	RCM	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 5L	HR15	2007	ABS	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 5L	HR15	2007	EPS	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 5L	HR15	2007	GEM	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 5L	HR15	2007	IC	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 5L	HR15	2007	IPDM	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 5L	HR15	2007	PCM	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 5L	HR15	2007	RCM	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 6L	HR16	2007	ABS	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 6L	HR16	2007	EPS	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 6L	HR16	2007	GEM	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 6L	HR16	2007	IC	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 6L	HR16	2007	IPDM	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 6L	HR16	2007	PCM	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 6L	HR16	2007	RCM	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 8L	MR18	2007	ABS	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 8L	MR18	2007	EPS	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 8L	MR18	2007	GEM	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 8L	MR18	2007	IC	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 8L	MR18	2007	IPDM	✓	✓	✓	✓	○
FAMILIA VAN (BV*Y12)	1. 8L	MR18	2007	PCM	✓	✓	✓	✓	○

FAMILIA VAN (B*Y12)	1. 8L	MR18	2007	RCM	✓	✓	✓	✓	○
FAMILIA WAGON/VAN (B*Y11_50000 0)	1. 3L	QG13	1999 - 2002	PCM	✓	✓	✓	✓	○
FAMILIA WAGON/VAN (B*Y11_50000 0)	1. 3L	QG13	2002	ABS	✓	✓	✓	✓	○
FAMILIA WAGON/VAN (B*Y11_50000 0)	1. 5L	QG15	1999 - 2002	PCM	✓	✓	✓	✓	○
FAMILIA WAGON/VAN (B*Y11_50000 0)	1. 5L	QG15	2002	ABS	✓	✓	✓	✓	○
FAMILIA WAGON/VAN (B*Y11_50000 0)	1. 8L	QG18	1999 - 2002	PCM	✓	✓	✓	✓	○
FRIENDEE / FREDA / BONGO FRIENDEE	2. 0L	FE	1997 - 2002	PCM	✓	✓	✓	✓	○
FRIENDEE / FREDA / BONGO FRIENDEE	2. 0L	FE	2002	TCM	✓	✓	✓	✓	○
FRIENDEE / FREDA / BONGO FRIENDEE	2. 5L	WL_T	1999	PCM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 0L	HCS	1996 - 1999	ABS/TCS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 0L	HCS	1996 - 1999	CSM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 0L	HCS	1996 - 1999	HEC	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 0L	HCS	1996 - 1999	PCM	✓	✓	✓	✓	0025 0023
Fiesta / Mazda_121 / Bantam	1. 0L	HCS	1999	ECS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 0L	Zetec Rocam	1999	ABS/TCS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 0L	Zetec Rocam	1999	CSM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 0L	Zetec Rocam	1999	ECS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 0L	Zetec Rocam	1999	GEM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 0L	Zetec Rocam	1999	HEC	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 0L	Zetec Rocam	1999	PCM	✓	✓	✓	✓	0023 0025
Fiesta / Mazda_121 / Bantam	1. 25L	Zetec-SE	1996 - 2000	ABS/TCS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 25L	Zetec-SE	1996 - 2000	CSM	✓	✓	✓	✓	○

Fiesta / Mazda_121 / Bantam	1. 25L	Zetec-SE	1996 - 2000	HEC	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 25L	Zetec-SE	1996 - 2000	PCM	✓	✓	✓	✓	0023 0025
Fiesta / Mazda_121 / Bantam	1. 25L	Zetec-SE	1999 - 2000	ECS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 25L	Zetec-SE	1999 - 2000	GEM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 25L	Zetec-SE	2000	PATS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1996 - 1999	ABS/TCS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1996 - 1999	CSM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1996 - 1999	HEC	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1996 - 1999	PCM	✓	✓	✓	✓	0023 0025 0009
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1999	ECS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1999	GEM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 4L	1. 4 PT-E SFI	1994 - 1996	ABS/TCS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 4L	1. 4 PT-E SFI	1994 - 1996	CSM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 4L	1. 4 PT-E SFI	1994 - 1996	HEC	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 4L	PT-E	2000	ABS/TCS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 4L	PT-E	2000	CSM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 4L	PT-E	2000	ECS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 4L	PT-E	2000	HEC	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 4L	PT-E	2000	PCM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1996 - 1999	ABS/TCS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1996 - 1999	CSM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1996 - 1999	HEC	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1996 - 1999	PCM	✓	✓	✓	✓	0023 0025 0009
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1999	ECS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1999	GEM	✓	✓	✓	✓	○

Fiesta / Mazda_121 / Bantam	1.6L	Other	2001	ABS/TCS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001	CSM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001	GEM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001	HEC	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001	PATS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001	PCM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999	ABS/TCS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999	CSM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999	ECS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999	GEM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999	HEC	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999	PCM	✓	✓	✓	✓	0023 0025
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000	ABS/TCS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000	CSM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000	ECS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000	GEM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000	HEC	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000	PCM	✓	✓	✓	✓	0009 0023 0025
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000	ABS/TCS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000	CSM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000	ECS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000	FIP	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000	GEM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000	HEC	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000	PATS	✓	✓	✓	✓	○

Fiesta / Mazda_121 / Bantam	1. 8L	Endura DI	2000	PCM	✓	✓	✓	✓	9
Fiesta / Mazda_121 / Bantam	1. 8L	Endura-DE	1996 - Other	ABS/TCS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 8L	Endura-DE	1996 - Other	CSM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 8L	Endura-DE	1996 - Other	ECS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 8L	Endura-DE	1996 - Other	HEC	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 8L	Endura-DE	1996 - Other	PATS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 8L	Endura-DE	1996 - Other	PCM	○	○	✓	○	○
Fiesta / Mazda_121 / Bantam	1. 8L	Zetec	1992 - 1994	ABS/TCS	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 8L	Zetec	1992 - 1994	CSM	✓	✓	✓	✓	○
Fiesta / Mazda_121 / Bantam	1. 8L	Zetec	1992 - 1994	HEC	✓	✓	✓	✓	○
LAPUTA	660cc	F6A-T	1998	TCM	✓	✓	✓	✓	○
LAPUTA	660cc	F6A-T	1998 - Other	ABS	✓	✓	✓	✓	○
LAPUTA	660cc	F6A-T	1998 - Other	PCM	✓	✓	✓	✓	○
LAPUTA	660cc	F6A-T	1998 - Other	RCM	✓	✓	✓	✓	○
LAPUTA	660cc	K6A	2000 - Other	ABS	✓	✓	✓	✓	○
LAPUTA	660cc	K6A	2000 - Other	PCM	✓	✓	✓	✓	○
LAPUTA	660cc	K6A	2000 - Other	RCM	✓	✓	✓	✓	○
LAPUTA	660cc	K6A_T	1999 - Other	ABS	✓	✓	✓	✓	○
LAPUTA	660cc	K6A_T	1999 - Other	PCM	✓	✓	✓	✓	○
LAPUTA	660cc	K6A_T	1999 - Other	RCM	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 3L	B3	1996 - Other	ABS	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 3L	B3	1996 - Other	PCM	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 3L	B3	2000	ABS/TCS	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 3L	Other	Other	PCM	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 5L	Other	Other	PCM	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 5L	Z5	1996 - Other	ABS	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 5L	Z5	1996 - Other	PCM	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 5L	ZL	1998 - Other	ABS	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 5L	ZL	1998 - Other	PCM	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 6L	B6	1996 - Other	ABS	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 6L	B6	1996 - Other	PCM	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 6L	Other	Other	PCM	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 6L	ZM	1998 - Other	ABS	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 6L	ZM	1998 - Other	PCM	✓	✓	✓	✓	○

LASER / 323 / TIERRA	1. 6L	ZM	2000	ABS/TCS	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 8L	BP	1996 - Other	ABS	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 8L	BP	1996 - Other	PCM	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 8L	FP	1998 - Other	ABS	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 8L	FP	1998 - Other	PCM	✓	✓	✓	✓	○
LASER / 323 / TIERRA	1. 8L	Other	Other	PCM	✓	✓	✓	✓	○
LASER / 323 / TIERRA	2. 0L	FS	2000	ABS/TCS	✓	✓	✓	✓	○
LASER / 323 / TIERRA	2. 0L	FS	2000 - 2001	ABS	✓	✓	✓	✓	○
LASER / 323 / TIERRA	2. 0L	FS	2000 - 2001	PCM	✓	✓	✓	✓	○
LASER / 323 / TIERRA	2. 0L	RF	1998	PCM	✓	✓	✓	✓	○
LASER / 323 / TIERRA	2. 0L	RF	1998 - Other	ABS	✓	✓	✓	✓	○
LASER / 323 / TIERRA	2. 0L	RF-T	1998 - 2000	PCM	✓	✓	✓	✓	○
LASER / 323 / TIERRA	2. 0L	RF-T	2000	ABS	✓	✓	✓	✓	○
MARVIE	2. 5L	G5	1996	PCM	✓	✓	✓	✓	○
MAZDA 929	3. 0L	JE	1997	PCM	✓	✓	✓	✓	○
MAZDA2 (China)	1. 3L	ZJ	2007	ABS	✓	✓	✓	✓	○
MAZDA2 (China)	1. 3L	ZJ	2007	BCM/GEM	✓	✓	✓	✓	○
MAZDA2 (China)	1. 3L	ZJ	2007	EPS	✓	✓	✓	✓	○
MAZDA2 (China)	1. 3L	ZJ	2007	IC	✓	✓	✓	✓	○
MAZDA2 (China)	1. 3L	ZJ	2007	PCM	✓	✓	✓	✓	○
MAZDA2 (China)	1. 3L	ZJ	2007	RCM	✓	✓	✓	✓	○
MAZDA2 (China)	1. 3L	ZJ	2007	RKE	✓	✓	✓	✓	○
MAZDA2 (China)	1. 5L	ZY	2007	ABS	✓	✓	✓	✓	○
MAZDA2 (China)	1. 5L	ZY	2007	BCM/GEM	✓	✓	✓	✓	○
MAZDA2 (China)	1. 5L	ZY	2007	EPS	✓	✓	✓	✓	○
MAZDA2 (China)	1. 5L	ZY	2007	IC	✓	✓	✓	✓	○
MAZDA2 (China)	1. 5L	ZY	2007	PCM	✓	✓	✓	✓	○
MAZDA2 (China)	1. 5L	ZY	2007	RCM	✓	✓	✓	✓	○
MAZDA2 (China)	1. 5L	ZY	2007	RKE	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 25L	MZI	2002 - 2006	ABS/TCS	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 25L	MZI	2002 - 2006	IC	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 25L	MZI	2002 - 2006	PCM	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 25L	MZI	2002 - 2006	RCM	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 4L	MZI	2002 - 2006	ABS/TCS	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 4L	MZI	2002 - 2006	IC	✓	✓	✓	✓	○

MAZDA2 (EURO STG3/4 Specs)	1. 4L	MZI	2002 - 2006	PCM	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 4L	MZI	2002 - 2006	RCM	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 4L	MZI	2002 - 2006	TCM	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 4L	MZ_CD_DI	2002 - 2006	ABS/TCS	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 4L	MZ_CD_DI	2002 - 2006	IC	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 4L	MZ_CD_DI	2002 - 2006	PCM	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 4L	MZ_CD_DI	2002 - 2006	RCM	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 4L	MZ_CD_DI	2002 - 2006	TCM	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 6L	MZI	2002	TCM	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 6L	MZI	2002 - 2006	ABS/TCS	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 6L	MZI	2002 - 2006	IC	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 6L	MZI	2002 - 2006	PCM	✓	✓	✓	✓	○
MAZDA2 (EURO STG3/4 Specs)	1. 6L	MZI	2002 - 2006	RCM	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 3L	ZJ	2007	ABS	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 3L	ZJ	2007	BCM/GEM	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 3L	ZJ	2007	EPS	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 3L	ZJ	2007	IC	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 3L	ZJ	2007	PCM	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 3L	ZJ	2007	RCM	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 3L	ZJ	2007	RKE	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 3L	ZJ	2007	VSM	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 4L	Y4	2007	ABS	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 4L	Y4	2007	BCM/GEM	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 4L	Y4	2007	EPS	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 4L	Y4	2007	IC	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 4L	Y4	2007	PCM	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 4L	Y4	2007	RCM	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 4L	Y4	2007	RKE	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 4L	Y4	2007	VSM	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 5L	ZY	2007	ABS	✓	✓	✓	✓	○
MAZDA2 (Europe)	1. 5L	ZY	2007	BCM/GEM	✓	✓	✓	✓	○

MAZDA2 (Europe)	1.5L	ZY	2007	EPS	✓	✓	✓	✓	○
MAZDA2 (Europe)	1.5L	ZY	2007	IC	✓	✓	✓	✓	○
MAZDA2 (Europe)	1.5L	ZY	2007	PCM	✓	✓	✓	✓	○
MAZDA2 (Europe)	1.5L	ZY	2007	RCM	✓	✓	✓	✓	○
MAZDA2 (Europe)	1.5L	ZY	2007	RKE	✓	✓	✓	✓	○
MAZDA2 (Europe)	1.5L	ZY	2007	VSM	✓	✓	✓	✓	○
MAZDA2 (Europe)	1.6L	Y6	2008	ABS	✓	✓	✓	✓	○
MAZDA2 (Europe)	1.6L	Y6	2008	BCM/GEM	✓	✓	✓	✓	○
MAZDA2 (Europe)	1.6L	Y6	2008	EPS	✓	✓	✓	✓	○
MAZDA2 (Europe)	1.6L	Y6	2008	IC	✓	✓	✓	✓	○
MAZDA2 (Europe)	1.6L	Y6	2008	PCM	✓	✓	✓	✓	○
MAZDA2 (Europe)	1.6L	Y6	2008	RCM	✓	✓	✓	✓	○
MAZDA2 (Europe)	1.6L	Y6	2008	RKE	✓	✓	✓	✓	○
MAZDA2 (Europe)	1.6L	Y6	2008	VSM	✓	✓	✓	✓	○
MAZDA3 (China / General)	1.6L	Z6	2007	ABS	✓	✓	✓	✓	○
MAZDA3 (China / General)	1.6L	Z6	2007	EATC	✓	✓	✓	✓	○
MAZDA3 (China / General)	1.6L	Z6	2007	GEM	✓	✓	✓	✓	○
MAZDA3 (China / General)	1.6L	Z6	2007	IC	✓	✓	✓	✓	○
MAZDA3 (China / General)	1.6L	Z6	2007	PCM	✓	✓	✓	✓	○
MAZDA3 (China / General)	1.6L	Z6	2007	RCM	✓	✓	✓	✓	○
MAZDA3 (China / General)	1.6L	Z6	2007	RKE	✓	✓	✓	✓	○
MAZDA3 (China / General)	2.0L	LF	2007	ABS	✓	✓	✓	✓	○
MAZDA3 (China / General)	2.0L	LF	2007	EATC	✓	✓	✓	✓	○
MAZDA3 (China / General)	2.0L	LF	2007	EPS	✓	✓	✓	✓	○
MAZDA3 (China / General)	2.0L	LF	2007	GEM	✓	✓	✓	✓	○
MAZDA3 (China / General)	2.0L	LF	2007	IC	✓	✓	✓	✓	○
MAZDA3 (China / General)	2.0L	LF	2007	PCM	✓	✓	✓	✓	○
MAZDA3 (China / General)	2.0L	LF	2007	RCM	✓	✓	✓	✓	○
MAZDA3 (China / General)	2.0L	LF	2007	RKE	✓	✓	✓	✓	○

MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 3L	ZJ	2003 - 2006	ABS	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 3L	ZJ	2003 - 2006	EATC	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 3L	ZJ	2003 - 2006	GEM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 3L	ZJ	2003 - 2006	IC	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 3L	ZJ	2003 - 2006	PCM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 3L	ZJ	2003 - 2006	RCM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 3L	ZJ	2006	RKE	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 6L	Y6	2003 - 2006	ABS	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 6L	Y6	2003 - 2006	EATC	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 6L	Y6	2003 - 2006	EPS	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 6L	Y6	2003 - 2006	FACM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 6L	Y6	2003 - 2006	GEM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 6L	Y6	2003 - 2006	IC	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 6L	Y6	2003 - 2006	PCM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 6L	Y6	2003 - 2006	RCM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 6L	Y6	2006	RKE	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 6L	Z6	2003 - 2006	ABS	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 6L	Z6	2003 - 2006	EATC	✓	✓	✓	✓	○

MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 6L	Z6	2003 - 2006	GEM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 6L	Z6	2003 - 2006	IC	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 6L	Z6	2003 - 2006	PCM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 6L	Z6	2003 - 2006	RCM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	1. 6L	Z6	2006	RKE	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2. 0L	LF	2003 - 2006	ABS	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2. 0L	LF	2003 - 2006	EATC	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2. 0L	LF	2003 - 2006	EPS	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2. 0L	LF	2003 - 2006	GEM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2. 0L	LF	2003 - 2006	IC	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2. 0L	LF	2003 - 2006	PCM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2. 0L	LF	2003 - 2006	RCM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2. 0L	LF	2006	RKE	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2. 0L	RF-T	2006	ABS	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2. 0L	RF-T	2006	EATC	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2. 0L	RF-T	2006	FFH	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2. 0L	RF-T	2006	GEM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs.)	2. 0L	RF-T	2006	IC	✓	✓	✓	✓	○

MAZDA3 (EURO STG3/4/5 and General Specs)	2. 0L	RF-T	2006	PCM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 0L	RF-T	2006	RCM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 0L	RF-T	2006	RKE	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 3L	L3	2003 - 2006	ABS	✓	✓	✓	✓	001E
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 3L	L3	2003 - 2006	EATC	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 3L	L3	2003 - 2006	EPS	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 3L	L3	2003 - 2006	GEM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 3L	L3	2003 - 2006	IC	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 3L	L3	2003 - 2006	PCM	✓	✓	✓	✓	9
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 3L	L3	2003 - 2006	RCM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 3L	L3	2006	RKE	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 3L	L3_T	2006	ABS	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 3L	L3_T	2006	EATC	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 3L	L3_T	2006	GEM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 3L	L3_T	2006	IC	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 3L	L3_T	2006	PCM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 3L	L3_T	2006	RCM	✓	✓	✓	✓	○
MAZDA3 (EURO STG3/4/5 and General Specs)	2. 3L	L3_T	2006	RKE	✓	✓	✓	✓	○

MAZDA3 (North America / General)	1.6L	Z6	2006	PCM	✓	✓	✓	✓	○
MAZDA3 (North America / General)	1.6L	Z6	2006	RKE	✓	✓	✓	✓	○
MAZDA3 (North America / General)	1.6L	Z6	2006	TPM	✓	✓	✓	✓	○
MAZDA3 (North America / General)	1.6L	Z6	2006 - 2012	ABS	✓	✓	✓	✓	○
MAZDA3 (North America / General)	1.6L	Z6	2006 - 2012	GEM	✓	✓	✓	✓	○
MAZDA3 (North America / General)	1.6L	Z6	2006 - 2012	IC	✓	✓	✓	✓	○
MAZDA3 (North America / General)	1.6L	Z6	2006 - 2012	RCM	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2.0L	LF	2004 - 2009	ABS	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2.0L	LF	2004 - 2009	EPS	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2.0L	LF	2004 - 2009	GEM	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2.0L	LF	2004 - 2009	IC	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2.0L	LF	2004 - 2009	PCM	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2.0L	LF	2004 - 2009	RCM	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2.0L	LF	2004 - 2009	TPM	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2.0L	LF	2006	EATC	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2.0L	LF	2006	RKE	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2.3L	L3	2004 - 2009	ABS	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2.3L	L3	2004 - 2009	EATC	✓	✓	✓	✓	○

MAZDA3 (North America / General)	2. 3L	L3	2004 - 2009	EPS	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2. 3L	L3	2004 - 2009	GEM	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2. 3L	L3	2004 - 2009	IC	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2. 3L	L3	2004 - 2009	PCM	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2. 3L	L3	2004 - 2009	RCM	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2. 3L	L3	2004 - 2009	TPM	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2. 3L	L3	2006	RKE	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2. 3L	L3	2006 - 2009	TCM	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2. 3L	L3_T	2007 - 2009	ABS	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2. 3L	L3_T	2007 - 2009	EATC	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2. 3L	L3_T	2007 - 2009	GEM	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2. 3L	L3_T	2007 - 2009	IC	✓	✓	✓	○	○
MAZDA3 (North America / General)	2. 3L	L3_T	2007 - 2009	PCM	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2. 3L	L3_T	2007 - 2009	RCM	✓	✓	✓	✓	○
MAZDA3 (North America / General)	2. 3L	L3_T	2007 - 2009	TPM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i- MAX	1. 8L	L8	2005	GEM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i- MAX	1. 8L	L8	2005 - 2007	ABS	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i- MAX	1. 8L	L8	2005 - 2007	EATC	✓	✓	✓	✓	○

MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 - 2007	EPS	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 - 2007	IC	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 - 2007	LPSDM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 - 2007	PCM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 - 2007	RCM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 - 2007	RKE	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 - 2007	RPSDM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007	TCM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 - 2007	ABS	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 - 2007	EATC	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 - 2007	EPS	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 - 2007	GEM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 - 2007	IC	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 - 2007	PCM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 - 2007	RCM	✓	✓	✓	✓	○

MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 - 2007	RKE	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007	LPSDM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007	RPSDM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007	TCM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 - 2007	ABS	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 - 2007	EATC	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 - 2007	FFH	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 - 2007	GEM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 - 2007	IC	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 - 2007	PCM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 - 2007	RCM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 - 2007	RKE	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007	LPSDM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007	RPSDM	✓	✓	✓	✓	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007	TCM	✓	✓	✓	✓	○

MAZDA5 (North America Specs.)	2. 3L	L3	2006 - 2010	ABS	√	√	√	√	○
MAZDA5 (North America Specs.)	2. 3L	L3	2006 - 2010	EATC	√	√	√	√	○
MAZDA5 (North America Specs.)	2. 3L	L3	2006 - 2010	EPS	√	√	√	√	○
MAZDA5 (North America Specs.)	2. 3L	L3	2006 - 2010	GEM	√	√	√	√	○
MAZDA5 (North America Specs.)	2. 3L	L3	2006 - 2010	IC	√	√	√	√	○
MAZDA5 (North America Specs.)	2. 3L	L3	2006 - 2010	PCM	√	√	√	√	○
MAZDA5 (North America Specs.)	2. 3L	L3	2006 - 2010	RCM	√	√	√	√	○
MAZDA5 (North America Specs.)	2. 3L	L3	2006 - 2010	TPM	√	√	√	√	○
MAZDA5 (North America Specs.)	2. 3L	L3	2008 - 2010	TCM	√	√	√	√	○
MAZDA6 (China)	2. 0L	LF	2007	ABS	√	√	√	√	○
MAZDA6 (China)	2. 0L	LF	2007	BCM/GEM	√	√	√	√	○
MAZDA6 (China)	2. 0L	LF	2007	EATC	√	√	√	√	○
MAZDA6 (China)	2. 0L	LF	2007	EPS	√	√	√	√	○
MAZDA6 (China)	2. 0L	LF	2007	IC	√	√	√	√	○
MAZDA6 (China)	2. 0L	LF	2007	LCM	√	√	√	√	○
MAZDA6 (China)	2. 0L	LF	2007	PCM	√	√	√	√	○
MAZDA6 (China)	2. 0L	LF	2007	RCM	√	√	√	√	○
MAZDA6 (China)	2. 0L	LF	2007	RKE	√	√	√	√	○
MAZDA6 (China)	2. 0L	LF	2007	TCM	√	√	√	√	○
MAZDA6 (China)	2. 5L	L5	2007	ABS	√	√	√	√	○
MAZDA6 (China)	2. 5L	L5	2007	BCM/GEM	√	√	√	√	○
MAZDA6 (China)	2. 5L	L5	2007	EATC	√	√	√	√	○
MAZDA6 (China)	2. 5L	L5	2007	EPS	√	√	√	√	○
MAZDA6 (China)	2. 5L	L5	2007	IC	√	√	√	√	○
MAZDA6 (China)	2. 5L	L5	2007	LCM	√	√	√	√	○
MAZDA6 (China)	2. 5L	L5	2007	PCM	√	√	√	√	○
MAZDA6 (China)	2. 5L	L5	2007	RCM	√	√	√	√	○
MAZDA6 (China)	2. 5L	L5	2007	RKE	√	√	√	√	○

MAZDA6 (China)	2. 5L	L5	2007	TCM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	1. 8L	L8	2002 - 2005	ABS/TCS	✓	✓	✓	✓	001E
MAZDA6 (EURO STG3/4 and General)	1. 8L	L8	2002 - 2005	IC	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	1. 8L	L8	2002 - 2005	LHID	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	1. 8L	L8	2002 - 2005	PCM	✓	✓	✓	✓	9
MAZDA6 (EURO STG3/4 and General)	1. 8L	L8	2002 - 2005	RCM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	1. 8L	L8	2002 - 2005	RHID	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	1. 8L	L8	2005	GEM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	1. 8L	L8	2005	LCM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	1. 8L	L8	2005	RKE	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	LF	2002 - 2005	ABS/TCS	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	LF	2002 - 2005	IC	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	LF	2002 - 2005	LHID	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	LF	2002 - 2005	PCM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	LF	2002 - 2005	RCM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	LF	2002 - 2005	RHID	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	LF	2005	GEM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	LF	2005	LCM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	LF	2005	RKE	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	LF	2005	TCM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	RF-T	2002 - 2005	ABS/TCS	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	RF-T	2002 - 2005	FFH	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	RF-T	2002 - 2005	IC	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	RF-T	2002 - 2005	LHID	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	RF-T	2002 - 2005	PCM	✓	✓	✓	✓	○

MAZDA6 (EURO STG3/4 and General)	2. 0L	RF-T	2002 - 2005	RCM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	RF-T	2002 - 2005	RHID	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	RF-T	2005	GEM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	RF-T	2005	LCM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 0L	RF-T	2005	RKE	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3	2002	4X4	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3	2002 - 2005	ABS/TCS	✓	✓	✓	✓	001E
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3	2002 - 2005	IC	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3	2002 - 2005	LHID	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3	2002 - 2005	PCM	✓	✓	✓	✓	9
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3	2002 - 2005	RCM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3	2002 - 2005	RHID	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3	2002 - 2005	TCM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3	2005	GEM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3	2005	LCM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3	2005	RKE	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3_T	2005	4X4	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3_T	2005	ABS/TCS	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3_T	2005	GEM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3_T	2005	IC	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3_T	2005	LCM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3_T	2005	LHID	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3_T	2005	PCM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3_T	2005	RCM	✓	✓	✓	✓	○
MAZDA6 (EURO STG3/4 and General)	2. 3L	L3_T	2005	RHID	✓	✓	✓	✓	○

MAZDA6 (EURO STG3/4 and General)	2. 3L	L3_T	2005	RKE	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	1. 8L	L8	2007	ABS	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	1. 8L	L8	2007	BCM/GEM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	1. 8L	L8	2007	EATC	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	1. 8L	L8	2007	EPS	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	1. 8L	L8	2007	IC	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	1. 8L	L8	2007	LCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	1. 8L	L8	2007	PCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	1. 8L	L8	2007	RCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	1. 8L	L8	2007	RKE	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	1. 8L	L8	2007	RVM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	1. 8L	L8	2007	TCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	LF	2007	ABS	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	LF	2007	BCM/GEM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	LF	2007	EATC	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	LF	2007	EPS	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	LF	2007	IC	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	LF	2007	LCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	LF	2007	PCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	LF	2007	RCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	LF	2007	RKE	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	LF	2007	RVM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	LF	2007	TCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	RF-T	2007	ABS	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	RF-T	2007	BCM/GEM	✓	✓	✓	✓	○

MAZDA6 (Europe and General)	2. 0L	RF-T	2007	EATC	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	RF-T	2007	EPS	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	RF-T	2007	FFH	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	RF-T	2007	IC	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	RF-T	2007	LCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	RF-T	2007	PCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	RF-T	2007	RCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	RF-T	2007	RKE	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	RF-T	2007	RVM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 0L	RF-T	2007	TCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 2L	R2_T	2007 - 2008	ABS	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 2L	R2_T	2007 - 2008	BCM/GEM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 2L	R2_T	2007 - 2008	EATC	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 2L	R2_T	2007 - 2008	EPS	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 2L	R2_T	2007 - 2008	FFH	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 2L	R2_T	2007 - 2008	IC	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 2L	R2_T	2007 - 2008	LCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 2L	R2_T	2007 - 2008	PCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 2L	R2_T	2007 - 2008	RCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 2L	R2_T	2007 - 2008	RKE	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 2L	R2_T	2007 - 2008	RVM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 2L	R2_T	2007 - 2008	TCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 5L	L5	2007	ABS	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 5L	L5	2007	BCM/GEM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2. 5L	L5	2007	EATC	✓	✓	✓	✓	○

MAZDA6 (Europe and General)	2.5L	L5	2007	EPS	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2.5L	L5	2007	IC	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2.5L	L5	2007	LCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2.5L	L5	2007	PCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2.5L	L5	2007	RCM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2.5L	L5	2007	RKE	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2.5L	L5	2007	RVM	✓	✓	✓	✓	○
MAZDA6 (Europe and General)	2.5L	L5	2007	TCM	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 - 2010	ABS	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 - 2010	BCM/GEM	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 - 2010	BSML	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 - 2010	BSMR	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 - 2010	EATC	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 - 2010	IC	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 - 2010	LCM	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 - 2010	PCM	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 - 2010	RCM	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 - 2010	RKE	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 - 2010	TCM	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 - 2010	ABS	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 - 2010	BCM/GEM	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 - 2010	BSML	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 - 2010	BSMR	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 - 2010	EATC	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 - 2010	IC	✓	✓	✓	✓	○

MAZDA6 (Middle East / General)	3. 7L	CA	2009 - 2010	LCM	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	3. 7L	CA	2009 - 2010	PCM	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	3. 7L	CA	2009 - 2010	RCM	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	3. 7L	CA	2009 - 2010	RKE	✓	✓	✓	✓	○
MAZDA6 (Middle East / General)	3. 7L	CA	2009 - 2010	TCM	✓	✓	✓	✓	○
MAZDA6 (North America / General)	2. 5L	L5	2009 - 2010	ABS	✓	✓	✓	✓	○
MAZDA6 (North America / General)	2. 5L	L5	2009 - 2010	BCM/GEM	✓	✓	✓	✓	○
MAZDA6 (North America / General)	2. 5L	L5	2009 - 2010	BSML	✓	✓	✓	✓	○
MAZDA6 (North America / General)	2. 5L	L5	2009 - 2010	BSMR	✓	✓	✓	✓	○
MAZDA6 (North America / General)	2. 5L	L5	2009 - 2010	EATC	✓	✓	✓	✓	○
MAZDA6 (North America / General)	2. 5L	L5	2009 - 2010	IC	✓	✓	✓	✓	○
MAZDA6 (North America / General)	2. 5L	L5	2009 - 2010	LCM	✓	✓	✓	✓	○
MAZDA6 (North America / General)	2. 5L	L5	2009 - 2010	PCM	✓	✓	✓	✓	○
MAZDA6 (North America / General)	2. 5L	L5	2009 - 2010	RCM	✓	✓	✓	✓	○
MAZDA6 (North America / General)	2. 5L	L5	2009 - 2010	RKE	✓	✓	✓	✓	○
MAZDA6 (North America / General)	2. 5L	L5	2009 - 2010	TCM	✓	✓	✓	✓	○
MAZDA6 (North America / General)	3. 7L	CA	2009 - 2010	ABS	✓	✓	✓	✓	○
MAZDA6 (North America / General)	3. 7L	CA	2009 - 2010	BCM/GEM	✓	✓	✓	✓	○
MAZDA6 (North America / General)	3. 7L	CA	2009 - 2010	BSML	✓	✓	✓	✓	○
MAZDA6 (North America / General)	3. 7L	CA	2009 - 2010	BSMR	✓	✓	✓	✓	○

MAZDA6 (North America / General)	3. 7L	CA	2009 - 2010	EATC	✓	✓	✓	✓	○
MAZDA6 (North America / General)	3. 7L	CA	2009 - 2010	IC	✓	✓	✓	✓	○
MAZDA6 (North America / General)	3. 7L	CA	2009 - 2010	LCM	✓	✓	✓	✓	○
MAZDA6 (North America / General)	3. 7L	CA	2009 - 2010	PCM	✓	✓	✓	✓	○
MAZDA6 (North America / General)	3. 7L	CA	2009 - 2010	RCM	✓	✓	✓	✓	○
MAZDA6 (North America / General)	3. 7L	CA	2009 - 2010	RKE	✓	✓	✓	✓	○
MAZDA6 (North America / General)	3. 7L	CA	2009 - 2010	TCM	✓	✓	✓	✓	○
MAZDA6(North America/Gene ral)	2. 3L	L3	2003 - 2008	ABS/TCS	✓	✓	✓	✓	○
MAZDA6(North America/Gene ral)	2. 3L	L3	2003 - 2008	IC	✓	✓	✓	✓	○
MAZDA6(North America/Gene ral)	2. 3L	L3	2003 - 2008	PCM	✓	✓	✓	✓	○
MAZDA6(North America/Gene ral)	2. 3L	L3	2003 - 2008	RCM	✓	✓	✓	✓	○
MAZDA6(North America/Gene ral)	2. 3L	L3	2003 - 2008	TCM	✓	✓	✓	✓	○
MAZDA6(North America/Gene ral)	2. 3L	L3	2006 - 2008	GEM	✓	✓	✓	✓	○
MAZDA6(North America/Gene ral)	2. 3L	L3	2008	TPM	✓	✓	✓	○	○
MAZDA6(North America/Gene ral)	2. 3L	L3_T	2006 - 2007	4X4	✓	✓	✓	✓	○
MAZDA6(North America/Gene ral)	2. 3L	L3_T	2006 - 2007	ABS/TCS	✓	✓	✓	✓	○
MAZDA6(North America/Gene ral)	2. 3L	L3_T	2006 - 2007	GEM	✓	✓	✓	✓	○
MAZDA6(North America/Gene ral)	2. 3L	L3_T	2006 - 2007	IC	✓	✓	✓	✓	○
MAZDA6(North America/Gene ral)	2. 3L	L3_T	2006 - 2007	PCM	✓	✓	✓	✓	○
MAZDA6(North America/Gene ral)	2. 3L	L3_T	2006 - 2007	RCM	✓	✓	✓	✓	○
MAZDA6(North America/Gene ral)	2. 3L	L3_T	2006 - 2007	RKE	✓	✓	✓	✓	○
MAZDA6(North America/Gene ral)	3. 0L	AJ	2003 - 2008	PCM	✓	✓	✓	✓	○

MAZDA6(North America/General)	3. 0L	AJ	2003 - 2008	TCM	✓	✓	✓	✓	○
MAZDA6(North America/General)	3. 0L	AJ	2003 - Other	ABS/TCS	✓	✓	✓	✓	○
MAZDA6(North America/General)	3. 0L	AJ	2003 - Other	IC	✓	✓	✓	✓	○
MAZDA6(North America/General)	3. 0L	AJ	2003 - Other	RCM	✓	✓	✓	✓	○
MAZDA6(North America/General)	3. 0L	AJ	2006 - 2008	GEM	✓	✓	✓	✓	○
MAZDA6(North America/General)	3. 0L	AJ	2008	TPM	✓	✓	✓	○	○
MILLENNIA / EUNOS 800	2. 0L	KF	1998 - 2000	ABS	✓	✓	✓	✓	○
MILLENNIA / EUNOS 800	2. 3L	KJ	1998 - 2000	ABS	✓	✓	✓	✓	○
MILLENNIA / EUNOS 800	2. 5L	KL	1998 - 2000	ABS	✓	✓	✓	✓	○
MILLENNIA / EUNOS 800	2. 5L	KL	2002	ABS/TCS	✓	✓	✓	✓	○
MILLENNIA / EUNOS 800	2. 5L	KL	2002	PCM	✓	✓	✓	✓	○
MPV (Europe/General)	2. 0L	FS	1999	ABS	✓	✓	✓	✓	○
MPV (Europe/General)	2. 0L	FS	1999 - 2000	PCM	✓	✓	✓	✓	○
MPV (Europe/General)	2. 0L	FS	2000	ABS/TCS	✓	✓	✓	✓	○
MPV (Europe/General)	2. 0L	RF-T	2002 - 2004	ABS/TCS	✓	✓	✓	✓	○
MPV (Europe/General)	2. 0L	RF-T	2002 - 2004	FFH	✓	✓	✓	✓	○
MPV (Europe/General)	2. 0L	RF-T	2002 - 2004	PCM	✓	✓	✓	✓	○
MPV (Europe/General)	2. 3L	L3	2002	ABS/TCS	✓	✓	✓	✓	○
MPV (Europe/General)	2. 3L	L3	2002	PCM	✓	✓	✓	✓	○
MPV (Europe/General)	2. 5L	GY	1999 - 2000	ABS	✓	✓	✓	✓	○
MPV (Europe/General)	2. 5L	GY	1999 - 2000	ABS/TCS	✓	✓	✓	✓	○
MPV (Europe/General)	2. 5L	GY	1999 - 2000	PCM	✓	✓	✓	✓	00C5 00C6
MPV (Europe/General)	3. 0L	AJ	2002	ABS/TCS	✓	✓	✓	✓	○
MPV (Europe/General)	3. 0L	AJ	2002	PCM	✓	✓	✓	✓	○
MPV (Europe/General)	3. 0L	AJ	2002	TCM	✓	✓	✓	✓	○
MPV (JPN/General)	2. 0L	FS	1999	ABS	✓	✓	✓	✓	○

MPV (JPN/General)	2. 0L	FS	1999	PCM	✓	✓	✓	✓	○
MPV (JPN/General)	2. 3L	L3	2002 - 2004	ABS/TCS	✓	✓	✓	✓	○
MPV (JPN/General)	2. 3L	L3	2002 - 2004	PCM	✓	✓	✓	✓	00C5 00C6
MPV (JPN/General)	2. 5L	GY	1999	ABS	✓	✓	✓	✓	○
MPV (JPN/General)	2. 5L	GY	1999	PCM	✓	✓	✓	✓	00C5 00C6
MPV (JPN/General)	3. 0L	AJ	2002 - 2004	ABS/TCS	✓	✓	✓	✓	○
MPV (JPN/General)	3. 0L	AJ	2002 - 2004	PCM	✓	✓	✓	✓	○
MPV (JPN/General)	3. 0L	AJ	2002 - 2004	TCM	✓	✓	✓	✓	○
MPV (North America / General)	2. 5L	GY	2000 - 2001	ABS/TCS	✓	✓	✓	✓	○
MPV (North America / General)	2. 5L	GY	2000 - 2001	PCM	✓	✓	✓	✓	00C5 00C6
MPV (North America / General)	3. 0L	AJ	2002 - 2006	ABS/TCS	✓	✓	✓	✓	○
MPV (North America / General)	3. 0L	AJ	2002 - 2006	PCM	✓	✓	✓	✓	00C5 00C6
MPV (North America / General)	3. 0L	AJ	2002 - 2006	TCM	✓	✓	✓	✓	00C5
MPV (North America / General)	3. 0L	AJ	2004 - 2006	RCM	✓	✓	✓	✓	○
MPV (North America / General)	3. 0L	JE	1997 - 1999	PCM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3	2006	4X4	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3	2006	ABS	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3	2006	AM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3	2006	GEM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3	2006	HCM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3	2006	IC	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3	2006	ICCM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3	2006	LCM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3	2006	LPSDM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3	2006	LTM	✓	✓	✓	✓	○

MPV / Mazda8 (JPN/General)	2. 3L	L3	2006	PCM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3	2006	RCM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3	2006	RKE	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3	2006	RPSDM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3	2006	TCM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3_T	2006	4X4	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3_T	2006	ABS	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3_T	2006	AM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3_T	2006	GEM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3_T	2006	HCM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3_T	2006	IC	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3_T	2006	ICCM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3_T	2006	LCM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3_T	2006	LPSDM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3_T	2006	LTM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3_T	2006	PCM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3_T	2006	RCM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3_T	2006	RKE	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3_T	2006	RPSDM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 3L	L3_T	2006	TCM	✓	✓	✓	○	○
MPV / Mazda8 (JPN/General)	2. 5L	L5	2012	ABS	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 5L	L5	2012	AM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 5L	L5	2012	GEM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 5L	L5	2012	HCM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2. 5L	L5	2012	ICCM	✓	✓	✓	✓	○

MPV / Mazda8 (JPN/General)	2.5L	L5	2012	LCM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012	LPSDM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012	LTM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012	RCM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012	RKE	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012	RPSDM	✓	✓	✓	✓	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012	TCM	✓	✓	✓	✓	○
MX-5 (Europe / General_ Specs.)	1.8L	L8	2005	TCM	✓	✓	✓	✓	○
MX-5 (Europe / General_ Specs.)	1.8L	L8	2005 - 2008	ABS	✓	✓	✓	✓	001E
MX-5 (Europe / General_ Specs.)	1.8L	L8	2005 - 2008	IC	✓	✓	✓	✓	○
MX-5 (Europe / General_ Specs.)	1.8L	L8	2005 - 2008	PCM	✓	✓	✓	✓	○
MX-5 (Europe / General_ Specs.)	1.8L	L8	2005 - 2008	RCM	✓	✓	✓	✓	○
MX-5 (Europe / General_ Specs.)	1.8L	L8	2005 - 2008	RHT	✓	✓	✓	✓	○
MX-5 (Europe / General_ Specs.)	1.8L	L8	2005 - 2008	RKE	✓	✓	✓	✓	○
MX-5 (Europe / General_ Specs.)	2.0L	LF	2005 - 2008	ABS	✓	✓	✓	✓	○
MX-5 (Europe / General_ Specs.)	2.0L	LF	2005 - 2008	IC	✓	✓	✓	✓	○
MX-5 (Europe / General_ Specs.)	2.0L	LF	2005 - 2008	PCM	✓	✓	✓	✓	○
MX-5 (Europe / General_ Specs.)	2.0L	LF	2005 - 2008	RCM	✓	✓	✓	✓	○
MX-5 (Europe / General_ Specs.)	2.0L	LF	2005 - 2008	RHT	✓	✓	✓	✓	○
MX-5 (Europe / General_ Specs.)	2.0L	LF	2005 - 2008	RKE	✓	✓	✓	✓	○
MX-5 (Europe / General_ Specs.)	2.0L	LF	2005 - 2008	TCM	✓	✓	✓	✓	○
MX-5 (North America / General Specs.)	2.0L	LF	2006 - Other	ABS	✓	✓	✓	✓	5
MX-5 (North America / General Specs.)	2.0L	LF	2006 - Other	IC	✓	✓	✓	✓	5
MX-5 (North America / General Specs.)	2.0L	LF	2006 - Other	PCM	✓	✓	✓	✓	○

MX-5 (North America / General Specs.)	2.0L	LF	2006 - Other	RCM	✓	✓	✓	✓	5
MX-5 (North America / General Specs.)	2.0L	LF	2006 - Other	RKE	✓	✓	✓	✓	5
MX-5 (North America / General Specs.)	2.0L	LF	2006 - Other	TCM	✓	✓	✓	✓	○
MX-5 (North America / General Specs.)	2.0L	LF	2007 - 2010	RHT	✓	✓	✓	✓	○
MX-5 MIATA	1.8L	BP	1997 - 2005	PCM	✓	✓	✓	✓	○
MX-5 MIATA	1.8L	BP	2001 - 2005	ABS/TCS	✓	✓	✓	✓	○
MX-5 MIATA	1.8L	BP Turbo	2004	ABS/TCS	✓	✓	✓	✓	○
MX-5 MIATA	1.8L	BP Turbo	2004	PCM	✓	✓	✓	✓	○
MX_5	1.6L	B6	2000	ABS/TCS	✓	✓	✓	✓	○
MX_5	1.6L	B6	2000	PCM	✓	✓	✓	✓	○
MX_5	1.8L	BP	2000	ABS/TCS	✓	✓	✓	✓	○
MX_5	1.8L	BP	2000	PCM	✓	✓	✓	✓	○
Millenia	2.3L	KJ	1997 - 2001	PCM	✓	✓	✓	✓	○
Millenia	2.3L	KJ	2000 - 2001	ABS/TCS	✓	✓	✓	✓	○
Millenia	2.5L	KL	1997 - 2001	PCM	✓	✓	✓	✓	○
Millenia	2.5L	KL	2000 - 2001	ABS/TCS	✓	✓	✓	✓	○
PREMACY	1.8L	FP	1999	ABS	✓	✓	✓	✓	○
PREMACY	1.8L	FP	2000	ABS/TCS	✓	✓	✓	✓	○
PREMACY	1.8L	FP	2000	PCM	✓	✓	✓	✓	○
PREMACY	2.0L	FS	2001	ABS	✓	✓	✓	✓	○
PREMACY	2.0L	FS	2001	ABS/TCS	✓	✓	✓	✓	○
PREMACY	2.0L	FS	2001	PCM	✓	✓	✓	✓	○
PREMACY	2.0L	RF-T	1999 - 2000	ABS	✓	✓	✓	✓	○
PREMACY	2.0L	RF-T	1999 - 2003	PCM	✓	✓	✓	✓	○
PREMACY	2.0L	RF-T	2000 - 2003	ABS/TCS	✓	✓	✓	✓	○
PREMACY / IXTION	1.8L	FP	1999	ABS	✓	✓	✓	✓	○
PREMACY / IXTION	1.8L	FP	1999 - 2002	PCM	✓	✓	✓	✓	○
PREMACY / IXTION	1.8L	FP	2002	ABS/TCS	✓	✓	✓	✓	○
PREMACY / IXTION	1.8L	FP_DE	1999	ABS	✓	✓	✓	✓	○
PREMACY / IXTION	1.8L	FP_DE	1999	PCM	✓	✓	✓	✓	○
PREMACY / IXTION	2.0L	FS	2001	ABS/TCS	✓	✓	✓	✓	○
PREMACY / IXTION	2.0L	FS	2001	PCM	✓	✓	✓	✓	○
PREMACY / IXTION	2.0L	RF-T	1999	ABS	✓	✓	✓	✓	○
PREMACY / IXTION	2.0L	RF-T	1999	PCM	✓	✓	✓	✓	○
PREMACY / MAZDA5	1.6L	Y6	Other	4X4	✓	✓	✓	✓	○
PREMACY / MAZDA5	1.6L	Y6	Other	ABS	✓	✓	✓	✓	○
PREMACY / MAZDA5	1.6L	Y6	Other	ACU	✓	✓	✓	✓	○
PREMACY / MAZDA5	1.6L	Y6	Other	BCM/GEM	✓	✓	✓	✓	○

PREMACY / MAZDA5	1. 6L	Y6	Other	EATC	✓	✓	✓	✓	○
PREMACY / MAZDA5	1. 6L	Y6	Other	EPS	✓	✓	✓	✓	○
PREMACY / MAZDA5	1. 6L	Y6	Other	IC	✓	✓	✓	✓	○
PREMACY / MAZDA5	1. 6L	Y6	Other	LPSDM	✓	✓	✓	✓	○
PREMACY / MAZDA5	1. 6L	Y6	Other	PCM	✓	✓	✓	✓	○
PREMACY / MAZDA5	1. 6L	Y6	Other	RCM	✓	✓	✓	✓	○
PREMACY / MAZDA5	1. 6L	Y6	Other	RKE	✓	✓	✓	✓	○
PREMACY / MAZDA5	1. 6L	Y6	Other	RPSDM	✓	✓	✓	✓	○
PREMACY / MAZDA5	1. 6L	Y6	Other	TCM	✓	✓	✓	✓	○
PREMACY / MAZDA5	1. 8L	L8	Other	ABS	✓	✓	✓	✓	001E
PREMACY / MAZDA5	1. 8L	L8	Other	ACU	✓	✓	✓	✓	○
PREMACY / MAZDA5	1. 8L	L8	Other	BCM/GEM	✓	✓	✓	✓	○
PREMACY / MAZDA5	1. 8L	L8	Other	EATC	✓	✓	✓	✓	○
PREMACY / MAZDA5	1. 8L	L8	Other	EPS	✓	✓	✓	✓	○
PREMACY / MAZDA5	1. 8L	L8	Other	IC	✓	✓	✓	✓	001A
PREMACY / MAZDA5	1. 8L	L8	Other	LPSDM	✓	✓	✓	✓	○
PREMACY / MAZDA5	1. 8L	L8	Other	PCM	✓	✓	✓	✓	9
PREMACY / MAZDA5	1. 8L	L8	Other	RCM	✓	✓	✓	✓	○
PREMACY / MAZDA5	1. 8L	L8	Other	RKE	✓	✓	✓	✓	○
PREMACY / MAZDA5	1. 8L	L8	Other	RPSDM	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 0L	LF	Other	4X4	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 0L	LF	Other	ABS	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 0L	LF	Other	ACU	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 0L	LF	Other	BCM/GEM	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 0L	LF	Other	EATC	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 0L	LF	Other	EPS	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 0L	LF	Other	IC	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 0L	LF	Other	LPSDM	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 0L	LF	Other	PCM	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 0L	LF	Other	RCM	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 0L	LF	Other	RKE	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 0L	LF	Other	RPSDM	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 0L	LF	Other	TCM	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 5L	L5	Other	ABS	✓	✓	✓	✓	001E
PREMACY / MAZDA5	2. 5L	L5	Other	ACU	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 5L	L5	Other	BCM/GEM	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 5L	L5	Other	EATC	✓	✓	✓	✓	○

PREMACY / MAZDA5	2. 5L	L5	Other	EPS	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 5L	L5	Other	IC	✓	✓	✓	✓	001A
PREMACY / MAZDA5	2. 5L	L5	Other	LPSDM	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 5L	L5	Other	PCM	✓	✓	✓	✓	9
PREMACY / MAZDA5	2. 5L	L5	Other	RCM	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 5L	L5	Other	RKE	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 5L	L5	Other	RPSDM	✓	✓	✓	✓	○
PREMACY / MAZDA5	2. 5L	L5	Other	TCM	✓	✓	✓	○	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 0L	LF	2005 - 2007	4X4	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 0L	LF	2005 - 2007	ABS	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 0L	LF	2005 - 2007	EATC	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 0L	LF	2005 - 2007	EPS	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 0L	LF	2005 - 2007	GEM	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 0L	LF	2005 - 2007	IC	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 0L	LF	2005 - 2007	PCM	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 0L	LF	2005 - 2007	RCM	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 0L	LF	2005 - 2007	RKE	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 0L	LF	2006 - 2007	LPSDM	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 0L	LF	2006 - 2007	RPSDM	✓	✓	✓	✓	○

PREMACY / MAZDA5 (Japan / General Specs.)	2. 0L	LF	2006 - 2007	TCM	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 3L	L3	2005 - 2007	ABS	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 3L	L3	2005 - 2007	EATC	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 3L	L3	2005 - 2007	EPS	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 3L	L3	2005 - 2007	GEM	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 3L	L3	2005 - 2007	IC	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 3L	L3	2005 - 2007	PCM	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 3L	L3	2005 - 2007	RCM	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 3L	L3	2005 - 2007	RKE	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 3L	L3	2007	LPSDM	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 3L	L3	2007	RPSDM	✓	✓	✓	✓	○
PREMACY / MAZDA5 (Japan / General Specs.)	2. 3L	L3	2007	TCM	✓	✓	✓	✓	○
PROBE / MX-6	2. 0L	Other	1996 - 1997	PCM	✓	✓	✓	✓	0023 0025
PROBE / MX-6	2. 5L	KL	1996 - 1997	PCM	✓	✓	✓	✓	○
PROCEED	2. 5L	G5	1996	PCM	✓	✓	✓	✓	○
PROCEED	2. 6L	G6	1996	PCM	✓	✓	✓	✓	○
PROTEGE	1. 5L	Z5	1997 - 1998	PCM	✓	✓	✓	✓	○
PROTEGE	1. 6L	ZM	1999 - 2001	PCM	✓	✓	✓	✓	○
PROTEGE	1. 6L	ZM	2000 - 2001	ABS/TCS	✓	✓	✓	✓	○
PROTEGE	1. 8L	BP	1997 - 1998	PCM	✓	✓	✓	✓	○
PROTEGE	1. 8L	FP	1999 - 2000	PCM	✓	✓	✓	✓	○

PROTEGE	1. 8L	FP	2000	ABS/TCS	✓	✓	✓	✓	○
PROTEGE	2. 0L	FS	2001 - 2003	ABS/TCS	✓	✓	✓	✓	○
PROTEGE	2. 0L	FS	2001 - 2003	PCM	✓	✓	✓	✓	○
PROTEGE	2. 0L	FS_T	2003	ABS/TCS	✓	✓	✓	✓	○
PROTEGE	2. 0L	FS_T	2003	PCM	✓	✓	✓	✓	○
ROADSTER / MX-5	1. 6L	B6	2000	ABS	✓	✓	✓	✓	○
ROADSTER / MX-5	1. 6L	B6	2002	ABS/TCS	✓	✓	✓	✓	○
ROADSTER / MX-5	1. 6L	B6	2002	PCM	✓	✓	✓	✓	○
ROADSTER / MX-5	1. 8L	BP	2000	ABS	✓	✓	✓	✓	○
ROADSTER / MX-5	1. 8L	BP	2002	ABS/TCS	✓	✓	✓	✓	○
ROADSTER / MX-5	1. 8L	BP	2002	PCM	✓	✓	✓	✓	○
ROADSTER / MX-5	1. 8L	BP Turbo	2003	ABS/TCS	✓	✓	✓	✓	○
ROADSTER / MX-5	1. 8L	BP Turbo	2003	PCM	✓	✓	✓	✓	○
ROADSTER / MX-5	2. 0L	LF	2005 - 2008	ABS	✓	✓	✓	✓	○
ROADSTER / MX-5	2. 0L	LF	2005 - 2008	IC	✓	✓	✓	✓	○
ROADSTER / MX-5	2. 0L	LF	2005 - 2008	PCM	✓	✓	✓	✓	○
ROADSTER / MX-5	2. 0L	LF	2005 - 2008	RCM	✓	✓	✓	✓	○
ROADSTER / MX-5	2. 0L	LF	2005 - 2008	RHT	✓	✓	✓	✓	○
ROADSTER / MX-5	2. 0L	LF	2005 - 2008	RKE	✓	✓	✓	✓	○
ROADSTER / MX-5	2. 0L	LF	2005 - 2008	TCM	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008	ABS	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008	ABS/TCS	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008	EPS	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008	IC	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008	LCM	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008	PCM	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008	RCM	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008	RKE	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008	SASM	✓	✓	✓	✓	○

RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008	TCM	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003	ABS/TCS	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003	EPS	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003	IC	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003	PCM	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003	RCM	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003	RKE	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003	SASM	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003	TCM	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003	ABS/TCS	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003	EPS	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003	IC	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003	PCM	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003	RCM	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003	RKE	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003	SASM	✓	✓	✓	✓	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003	TCM	✓	✓	✓	✓	○
RX-8 (North America Specs.)	654x2cc	13B	2009 - 2010	ABS	✓	✓	✓	✓	○
RX-8 (North America Specs.)	654x2cc	13B	2009 - 2010	ABS/TCS	✓	✓	✓	✓	○

RX-8 (North America Specs)	654x2cc	13B	2009 - 2010	EPS	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B	2009 - 2010	IC	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B	2009 - 2010	LCM	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B	2009 - 2010	PCM	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B	2009 - 2010	RCM	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B	2009 - 2010	RKE	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B	2009 - 2010	SASM	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B	2009 - 2010	TCM	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B	2009 - 2010	TPM	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 - 2008	ABS/TCS	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 - 2008	EPS	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 - 2008	IC	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 - 2008	PCM	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 - 2008	RCM	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 - 2008	RKE	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 - 2008	SASM	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 - 2008	TPM	✓	✓	✓	○	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 - 2008	TCM	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 - 2005	ABS/TCS	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 - 2005	EPS	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 - 2005	IC	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 - 2005	PCM	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 - 2005	RCM	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 - 2005	RKE	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 - 2005	SASM	✓	✓	✓	✓	○

RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 - 2005	TCM	✓	✓	✓	✓	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 - 2005	TPM	✓	✓	✓	○	○
Ranger	2. 3L	DURATEC-HE / I4	2009	4X4	✓	✓	✓	✓	○
Ranger	2. 3L	DURATEC-HE / I4	2009	ABS/TCS	✓	✓	✓	✓	8
Ranger	2. 3L	DURATEC-HE / I4	2009	GEM	✓	✓	✓	✓	○
Ranger	2. 3L	DURATEC-HE / I4	2009	IC	✓	✓	✓	✓	9
Ranger	2. 3L	DURATEC-HE / I4	2009	PCM	✓	✓	✓	✓	0023 0025
Ranger	2. 3L	DURATEC-HE / I4	2009	RCM	✓	✓	✓	✓	○
Ranger	2. 3L	DURATEC-HE / I4	2009	TBM	✓	✓	✓	✓	○
Ranger / Courier / Mazda B Series / Bravo	4. 0L	V6 SOHC	2003	ABS/TCS	✓	✓	✓	✓	8
Ranger / Courier / Mazda B Series / Bravo	4. 0L	V6 SOHC	2003	ESOF	✓	✓	✓	✓	○
Ranger / Courier / Mazda B Series / Bravo	4. 0L	V6 SOHC	2003	PCM	✓	✓	✓	✓	0009 0023 0025
Ranger / Mazda B Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	ABS	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	ACM	✓	✓	✓	○	○
Ranger / Mazda B Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	PAM	✓	✓	✓	○	○
Ranger / Mazda B Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	PCM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	✓	✓	✓	✓	○

Ranger / Mazda B Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	RCM	✓	✓	✓	○	○
Ranger / Mazda B Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	SRM	✓	✓	✓	○	○
Ranger / Mazda B Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	TBM	✓	✓	✓	○	○
Ranger / Mazda B Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	TCM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2004 - 2007	GEM	✓	✓	✓	✓	000A
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2004 - 2009	ABS/TCS	✓	✓	✓	✓	8
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2004 - 2011	4X4	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2004 - 2011	IC	✓	✓	✓	✓	9
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2004 - 2011	PCM	✓	✓	✓	✓	0009 0023 0025 0010 0028 0031 0033
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2004 - 2011	RCM	✓	✓	✓	✓	000C
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2005	TPM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2007 - 2011	OCSM	✓	✓	✓	○	000C
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2007 - 2011	SDARS	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2008 - 2011	GEM / SJB	✓	✓	✓	✓	000A 0042
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2010 - 2011	ABS	✓	✓	✓	✓	0008 0012
Ranger / Mazda B Series / Courier	2. 3L	OHC	1995 - 1997	ABS/TCS	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 3L	OHC	1995 - 1997	GEM	✓	✓	✓	✓	○

Ranger / Mazda B Series / Courier	2. 3L	OHC	1995 - 1997	PCM	✓	✓	✓	✓	0023 0025
Ranger / Mazda B Series / Courier	2. 3L	OHC	1995 - 1997	RAP	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 3L	OHC	1996 - 1997	IAB	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 3L	Other	1996 - 2003	ABS/TCS	✓	✓	✓	✓	8
Ranger / Mazda B Series / Courier	2. 3L	Other	1996 - 2003	GEM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 3L	Other	1996 - 2003	PCM	✓	✓	✓	✓	0023 0025 0009 0010 0028 0031 0033
Ranger / Mazda B Series / Courier	2. 3L	Other	2001	PATS	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 3L	Other	2001 - 2003	4X4	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 3L	Other	2001 - 2003	RAP	✓	✓	✓	✓	000A 000F
Ranger / Mazda B Series / Courier	2. 3L	Other	2001 - 2003	RCM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 5L	DURATEC-HE / I4	2011	ABS	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 5L	DURATEC-HE / I4	2011	ACM	✓	✓	✓	○	○
Ranger / Mazda B Series / Courier	2. 5L	DURATEC-HE / I4	2011	BCMii	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 5L	DURATEC-HE / I4	2011	DDM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 5L	DURATEC-HE / I4	2011	FCDIM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 5L	DURATEC-HE / I4	2011	HVAC	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 5L	DURATEC-HE / I4	2011	IPC	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2. 5L	DURATEC-HE / I4	2011	PAM	✓	✓	✓	○	○

Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	PCM	✓	✓	✓	✓	25
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	PDM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	RCM	✓	✓	✓	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	SRM	✓	✓	✓	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	TBM	✓	✓	✓	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	TCM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011	TRM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2.5L	Other	1998	IAB	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2.5L	Other	1998 - 2001	ABS/TCS	✓	✓	✓	✓	8
Ranger / Mazda B Series / Courier	2.5L	Other	1998 - 2001	GEM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2.5L	Other	1998 - 2001	PCM	✓	✓	✓	✓	0023 0025 0010 0028 0031 0033
Ranger / Mazda B Series / Courier	2.5L	Other	1998 - 2001	RAP	✓	✓	✓	✓	000A
Ranger / Mazda B Series / Courier	2.5L	Other	1999 - 2001	PATS	✓	✓	✓	✓	9
Ranger / Mazda B Series / Courier	2.5L	Other	1999 - 2001	RCM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2.5L	Other	2001	4X4	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001	4X4	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001	ABS/TCS	✓	✓	✓	✓	8
Ranger / Mazda B Series / Courier	2.8L	Other	2001	GEM	✓	✓	✓	✓	○

Ranger / Mazda B Series / Courier	2.8L	Other	2001	PATS	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001	PCM	✓	✓	✓	✓	9
Ranger / Mazda B Series / Courier	2.8L	Other	2001	RAP	✓	✓	✓	✓	000A
Ranger / Mazda B Series / Courier	2.8L	Other	2001	RCM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	ABS/TCS	✓	✓	✓	✓	8
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	GEM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	PATS	✓	✓	✓	✓	9
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	PCM	✓	✓	✓	✓	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	RAP	✓	✓	✓	✓	000A
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 - 2000	RCM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	3.0L	Other	1995 - 2003	RAP	✓	✓	✓	✓	000A
Ranger / Mazda B Series / Courier	3.0L	Other	1995 - 2007	GEM	✓	✓	✓	✓	000A
Ranger / Mazda B Series / Courier	3.0L	Other	1995 - 2008	ABS/TCS	✓	✓	✓	✓	8
Ranger / Mazda B Series / Courier	3.0L	Other	1995 - 2008	PCM	✓	✓	✓	✓	0023 0025 0010 0028 0031 0033 0009
Ranger / Mazda B Series / Courier	3.0L	Other	1996 - 1998	IAB	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	3.0L	Other	1999 - 2008	RCM	✓	✓	✓	✓	000C
Ranger / Mazda B Series / Courier	3.0L	Other	2000 - 2001	PATS	✓	✓	✓	✓	9
Ranger / Mazda B Series / Courier	3.0L	Other	2001 - 2008	4X4	✓	✓	✓	✓	○

Ranger / Mazda B Series / Courier	3.0L	Other	2004 - 2008	IC	✓	✓	✓	✓	9
Ranger / Mazda B Series / Courier	3.0L	Other	2005	TPM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	3.0L	Other	2007 - 2008	OCSM	✓	✓	✓	○	000C
Ranger / Mazda B Series / Courier	3.0L	Other	2007 - 2008	SDARS	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	3.0L	Other	2008	GEM / SJB	✓	✓	✓	✓	000A 0042
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	ABS	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	ACM	✓	✓	✓	○	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PAM	✓	✓	✓	○	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PCM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	RCM	✓	✓	✓	○	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	SRM	✓	✓	✓	○	○
Ranger / Mazda B Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TBM	✓	✓	✓	○	○

Ranger / Mazda B Series / Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	TCM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	4. 0L	Other	1995 - 2002	ABS/TCS	✓	✓	✓	✓	8
Ranger / Mazda B Series / Courier	4. 0L	Other	1995 - 2002	GEM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	4. 0L	Other	1995 - 2002	PCM	✓	✓	✓	✓	0023 0025 0010 0028 0031 0033 0009
Ranger / Mazda B Series / Courier	4. 0L	Other	1995 - 2002	RAP	✓	✓	✓	✓	000A
Ranger / Mazda B Series / Courier	4. 0L	Other	1996 - 1998	IAB	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	4. 0L	Other	1999 - 2001	PATS	✓	✓	✓	✓	9
Ranger / Mazda B Series / Courier	4. 0L	Other	1999 - 2002	RCM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	4. 0L	Other	2001 - 2002	4X4	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2003	RAP	✓	✓	✓	✓	000A 000F
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2003 - 2007	GEM	✓	✓	✓	✓	000A
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2003 - 2009	ABS/TCS	✓	✓	✓	✓	8
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2003 - 2011	4X4	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2003 - 2011	PCM	✓	✓	✓	✓	0009 0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2003 - 2011	RCM	✓	✓	✓	✓	000C
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2004 - 2011	IC	✓	✓	✓	✓	9
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2005	TPM	✓	✓	✓	✓	○

Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 - 2011	OCSM	✓	✓	✓	○	000C
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 - 2011	SDARS	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 - 2011	GEM / SJB	✓	✓	✓	✓	000A 0042
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 - 2011	ABS	✓	✓	✓	✓	0008 0012
Ranger / Mazda B Series / Courier	Other	Other	2004	4X4	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	Other	Other	2004	ABS/TCS	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	Other	Other	2004	GEM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	Other	Other	2004	IC	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	Other	Other	2004	PCM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	Other	Other	2004 - 2011	RCM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	Other	Other	2011	ABS	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	Other	Other	2011	ACM	✓	✓	✓	○	○
Ranger / Mazda B Series / Courier	Other	Other	2011	BCMii	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	Other	Other	2011	DDM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	Other	Other	2011	FCDIM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	Other	Other	2011	HVAC	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	Other	Other	2011	IPC	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	Other	Other	2011	PAM	✓	✓	✓	○	○

Ranger / Mazda B Series / Courier	Other	Other	2011	PDM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	Other	Other	2011	SRM	✓	✓	✓	○	○
Ranger / Mazda B Series / Courier	Other	Other	2011	TBM	✓	✓	✓	○	○
Ranger / Mazda B Series / Courier	Other	Other	2011	TCM	✓	✓	✓	✓	○
Ranger / Mazda B Series / Courier	Other	Other	2011	TRM	✓	✓	✓	✓	○
SCRUM	660cc	F6A	1999 - Other	ABS	✓	✓	✓	✓	○
SCRUM	660cc	F6A	1999 - Other	PCM	✓	✓	✓	✓	○
SCRUM	660cc	F6A	1999 - Other	RCM	✓	✓	✓	✓	○
SCRUM	660cc	F6A-T	1999 - Other	ABS	✓	✓	✓	✓	○
SCRUM	660cc	F6A-T	1999 - Other	PCM	✓	✓	✓	✓	○
SCRUM	660cc	F6A-T	1999 - Other	RCM	✓	✓	✓	✓	○
SCRUM	660cc	F6A-T	1999 - Other	TCM	✓	✓	✓	✓	○
SCRUM	660cc	K6A	2001 - Other	ABS	✓	✓	✓	✓	○
SCRUM	660cc	K6A	2001 - Other	PCM	✓	✓	✓	✓	○
SCRUM	660cc	K6A	2001 - Other	RCM	✓	✓	✓	✓	○
SCRUM	660cc	K6A_T	2001 - Other	ABS	✓	✓	✓	✓	○
SCRUM	660cc	K6A_T	2001 - Other	PCM	✓	✓	✓	✓	○
SCRUM	660cc	K6A_T	2001 - Other	RCM	✓	✓	✓	✓	○
SCRUM	660cc	K6A_T	2001 - Other	TCM	✓	✓	✓	✓	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	2005	ABS	✓	✓	✓	✓	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	2005	PCM	✓	✓	✓	✓	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	2005	RCM	✓	✓	✓	✓	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	2005	ABS	✓	✓	✓	✓	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	2005	PCM	✓	✓	✓	✓	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	2005	RCM	✓	✓	✓	✓	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	2005	TCM	✓	✓	✓	✓	○
SCRUM_ (2003 / 9 -)	660cc	K6A	2003 - Other	ABS	✓	✓	✓	✓	○
SCRUM_ (2003 / 9 -)	660cc	K6A	2003 - Other	PCM	✓	✓	✓	✓	○
SCRUM_ (2003 / 9 -)	660cc	K6A	2003 - Other	RCM	✓	✓	✓	✓	○
SCRUM_ (2003 / 9 -)	660cc	K6A_T	2003 - Other	ABS	✓	✓	✓	✓	○
SCRUM_ (2003 / 9 -)	660cc	K6A_T	2003 - Other	PCM	✓	✓	✓	✓	○
SCRUM_ (2003 / 9 -)	660cc	K6A_T	2003 - Other	RCM	✓	✓	✓	✓	○

SCRUM_(2003 / 9 -)	660cc	K6A_T	2003 - Other	TCM	✓	✓	✓	✓	○
SENTIA	3.0L	JE	1997	PCM	✓	✓	✓	✓	○
SENTIA	3.0L	JE_HO	1997	PCM	✓	✓	✓	✓	○
TITAN_DASH	2.0L	FE	2000 - 2002	PCM	✓	✓	✓	✓	○
TITAN_DASH	2.0L	FE	2002	TCM	✓	✓	✓	✓	○
TITAN_DASH	2.0L	FE LPG	2002	PCM	✓	✓	✓	✓	○
TITAN_DASH	2.0L	FE LPG	2002	TCM	✓	✓	✓	✓	○
TITAN_DASH	2.0L	RF-T	2004	PCM	✓	✓	✓	✓	○
TITAN_DASH	2.0L	RF-T	2004	TCM	✓	✓	✓	✓	○
XEDOS9	2.0L	KF	1996	ABS	✓	✓	✓	✓	○
XEDOS9	2.3L	KJ	1996 - 1998	ABS	✓	✓	✓	✓	○
XEDOS9	2.5L	KL	1996 - 2000	ABS	✓	✓	✓	✓	○
XEDOS9	2.5L	KL	2000	ABS/TCS	✓	✓	✓	✓	○
XEDOS9	2.5L	KL	2000	PCM	✓	✓	✓	✓	○