

Auto Maker: Infiniti
Version: V5.00

NOTES:

- ✓ This function is supported.
 - This function is not supported.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
 - ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

Car	Type	Year	System	ECU Info	Read Codes	Erase Codes	Freeze Date	Live Data
*INFINITI EX35 Camp:P8202	J50	2008	AIRBAG	✓	✓	✓	✓	✓
*INFINITI EX35 Camp:P8202	J50	2008	TRANSMISSION	✓	✓	✓	○	✓
INFINITI EX25/EX35	J50	2009-2012	ABS	✓	✓	✓	※	✓
INFINITI EX25/EX35	J50	2009-2012	ACCELE PEDAL ACT	✓	✓	✓	○	✓
INFINITI EX25/EX35	J50	2009-2012	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI EX25/EX35	J50	2009-2012	AIRBAG	✓	✓	✓	✓	✓
INFINITI EX25/EX35	J50	2009-2012	ALL MODE AWD4WD	✓	✓	✓	○	✓
INFINITI EX25/EX35	J50	2009-2012	AUTO DRIVE POS	✓	✓	✓	○	✓
INFINITI EX25/EX35	J50	2009-2012	BCM	※	✓	✓	○	✓
INFINITI EX25/EX35	J50	2009-2012	ENGINE	✓	✓	✓	※	✓
INFINITI EX25/EX35	J50	2009-2012	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI EX25/EX35	J50	2009-2012	IPDM ER	○	✓	✓	○	✓
INFINITI EX25/EX35	J50	2009-2012	METER	※	✓	✓	○	✓
INFINITI EX25/EX35	J50	2009-2012	MULTI AV	※	✓	✓	○	✓
INFINITI EX25/EX35	J50	2009-2012	PRECRASH SEATBELT	✓	✓	✓	○	✓
INFINITI EX25/EX35	J50	2009-2012	SIDE RADAR LEFT	✓	✓	✓	○	✓
INFINITI EX25/EX35	J50	2009-2012	SIDE RADAR RIGHT	✓	✓	✓	○	✓
INFINITI EX25/EX35	J50	2009-2012	SONAR	✓	✓	✓	○	✓
INFINITI EX25/EX35	J50	2009-2012	ICC	✓	✓	✓	※	✓
INFINITI EX25/EX35	J50	2009-2012	TRANSMISSION	✓	✓	✓	※	✓
INFINITI EX25/EX35	J50	2009-2012	LANE CAMERA	✓	✓	✓	○	✓
INFINITI EX35	J50	2007-2012	ABS	✓	✓	✓	※	✓
INFINITI EX35	J50	2007-2012	ACCELE PEDAL ACT	✓	✓	✓	○	✓
INFINITI EX35	J50	2007-2012	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI EX35	J50	2007-2012	AIRBAG	✓	✓	✓	✓	✓
INFINITI EX35	J50	2007-2012	ALL MODE AWD4WD	✓	✓	✓	○	✓
INFINITI EX35	J50	2007-2012	AUTO DRIVE POS	✓	✓	✓	○	✓
INFINITI EX35	J50	2007-2012	BCM	※	✓	✓	○	✓
INFINITI EX35	J50	2007-2012	ENGINE	✓	✓	✓	※	✓
INFINITI EX35	J50	2007-2012	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI EX35	J50	2007-2012	HVAC	✓	✓	✓	○	✓
INFINITI EX35	J50	2007-2012	INTELLIGENT KEY	✓	✓	✓	○	✓
INFINITI EX35	J50	2007-2012	IPDM ER	○	✓	✓	○	✓
INFINITI EX35	J50	2007-2012	LANE CAMERA	✓	✓	✓	○	✓
INFINITI EX35	J50	2007-2012	METER	※	✓	✓	○	✓
INFINITI EX35	J50	2007-2012	MULTI AV	※	✓	✓	○	✓
INFINITI EX35	J50	2007-2012	POP UP HOOD	✓	✓	✓	○	✓
INFINITI EX35	J50	2007-2012	REARVIEW CAMERA	✓	○	○	○	✓
INFINITI EX35	J50	2007-2012	SBLIND CAMERA	✓	○	○	○	✓
INFINITI EX35	J50	2007-2012	SONAR	✓	✓	✓	○	✓
INFINITI EX35	J50	2007-2012	ICC	✓	✓	✓	※	✓
INFINITI EX35	J50	2007-2012	TRANSMISSION	✓	✓	✓	※	✓
INFINITI EX35 (DOM)	J50	2009-2011	ABS	✓	✓	✓	※	✓
INFINITI EX35 (DOM)	J50	2009-2011	ACCELE PEDAL ACT	✓	✓	✓	○	✓
INFINITI EX35 (DOM)	J50	2009-2011	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI EX35 (DOM)	J50	2009-2011	AIRBAG	✓	✓	✓	✓	✓
INFINITI EX35 (DOM)	J50	2009-2011	ALL MODE AWD4WD	✓	✓	✓	○	✓
INFINITI EX35 (DOM)	J50	2009-2011	AUTO DRIVE POS	✓	✓	✓	○	✓
INFINITI EX35 (DOM)	J50	2009-2011	BCM	※	✓	✓	○	✓
INFINITI EX35 (DOM)	J50	2009-2011	ENGINE	✓	✓	✓	※	✓
INFINITI EX35 (DOM)	J50	2009-2011	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI EX35 (DOM)	J50	2009-2011	IPDM ER	○	✓	✓	○	✓
INFINITI EX35 (DOM)	J50	2009-2011	LANE CAMERA	✓	✓	✓	○	✓
INFINITI EX35 (DOM)	J50	2009-2011	METER	※	✓	✓	○	✓
INFINITI EX35 (DOM)	J50	2009-2011	MULTI AV	※	✓	✓	○	✓
INFINITI EX35 (DOM)	J50	2009-2011	PRECRASH SEATBELT	✓	✓	✓	○	✓
INFINITI EX35 (DOM)	J50	2009-2011	SONAR	✓	✓	✓	○	✓
INFINITI EX35 (DOM)	J50	2009-2011	ICC	✓	✓	✓	※	✓

INFINITI EX35 (DOM)	I50	2009-2011	TRANSMISSION	✓	✓	✓	※	✓
INFINITI EX35/EX30d	J50	2009-2011	ABS	✓	✓	✓	※	✓
INFINITI EX35/EX30d	J50	2009-2011	ACCELE_PEDAL_ACT	✓	✓	✓	○	✓
INFINITI EX35/EX30d	J50	2009-2011	ADAPTIVE_LIGHT	✓	✓	✓	○	✓
INFINITI EX35/EX30d	J50	2009-2011	AIRBAG	✓	✓	✓	✓	✓
INFINITI EX35/EX30d	J50	2009-2011	ALL_MODE_AWD4WD	✓	✓	✓	○	✓
INFINITI EX35/EX30d	J50	2009-2011	AUTO_DRIVE_POS	✓	✓	✓	○	✓
INFINITI EX35/EX30d	J50	2009-2011	BCM	※	✓	✓	○	✓
INFINITI EX35/EX30d	J50	2009-2011	ENGINE	✓	✓	✓	※	✓
INFINITI EX35/EX30d	J50	2009-2011	HEAD_LAMP_LEVELIZER	✓	✓	✓	○	✓
INFINITI EX35/EX30d	J50	2009-2011	IPDM_ER	○	✓	✓	○	✓
INFINITI EX35/EX30d	J50	2009-2011	LANE_CAMERA	✓	✓	✓	○	✓
INFINITI EX35/EX30d	J50	2009-2011	METER	※	✓	✓	○	✓
INFINITI EX35/EX30d	J50	2009-2011	MULTI_AV	※	✓	✓	○	✓
INFINITI EX35/EX30d	J50	2009-2011	PRECRASH_SEATBELT	✓	✓	✓	○	✓
INFINITI EX35/EX30d	J50	2009-2011	SIDE_RADAR_LEFT	✓	✓	✓	○	✓
INFINITI EX35/EX30d	J50	2009-2011	SIDE_RADAR_RIGHT	✓	✓	✓	○	✓
INFINITI EX35/EX30d	J50	2009-2011	SONAR	✓	✓	✓	○	✓
INFINITI EX35/EX30d	J50	2009-2011	ICC	✓	✓	✓	※	✓
INFINITI EX35/EX30d	J50	2009-2011	BSW	✓	✓	✓	○	✓
INFINITI EX35/EX30d	J50	2009-2011	TRANSMISSION	✓	✓	✓	※	✓
INFINITI EX35/EX37	I50	2011	ABS	✓	✓	✓	※	✓
INFINITI EX35/EX37	I50	2011	ACCELE PEDAL ACT	✓	✓	✓	○	✓
INFINITI EX35/EX37	I50	2011	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI EX35/EX37	I50	2011	AIRBAG	✓	✓	✓	✓	✓
INFINITI EX35/EX37	I50	2011	ALL_MODE_AWD4WD	✓	✓	✓	○	✓
INFINITI EX35/EX37	I50	2011	AUTO_DRIVE_POS	✓	✓	✓	○	✓
INFINITI EX35/EX37	I50	2011	BCM	※	✓	✓	○	✓
INFINITI EX35/EX37	I50	2011	ENGINE	✓	✓	✓	※	✓
INFINITI EX35/EX37	I50	2011	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI EX35/EX37	I50	2011	IPDM_ER	○	✓	✓	○	✓
INFINITI EX35/EX37	I50	2011	LANE CAMERA	✓	✓	✓	○	✓
INFINITI EX35/EX37	I50	2011	METER	※	✓	✓	○	✓
INFINITI EX35/EX37	I50	2011	MULTI_AV	※	✓	✓	○	✓
INFINITI EX35/EX37	I50	2011	PRECRASH SEATBELT	✓	✓	✓	○	✓
INFINITI EX35/EX37	I50	2011	SIDE RADAR LEFT	✓	✓	✓	○	✓
INFINITI EX35/EX37	I50	2011	SIDE RADAR RIGHT	✓	✓	✓	○	✓
INFINITI EX35/EX37	I50	2011	SONAR	✓	✓	✓	○	✓
INFINITI EX35/EX37	I50	2011	ICC	✓	✓	✓	※	✓
INFINITI EX35/EX37	I50	2011	BSW	✓	✓	✓	○	✓
INFINITI EX35/EX37	I50	2011	TRANSMISSION	✓	✓	✓	※	✓
INFINITI EX37	I50	2008-2012	ABS	✓	✓	✓	※	✓
INFINITI EX37	I50	2008-2012	ACCELE PEDAL ACT	✓	✓	✓	○	✓
INFINITI EX37	I50	2008-2012	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI EX37	I50	2008-2012	AIRBAG	✓	✓	✓	✓	✓
INFINITI EX37	I50	2008-2012	ALL_MODE_AWD4WD	✓	✓	✓	○	✓
INFINITI EX37	I50	2008-2012	AUTO_DRIVE_POS	✓	✓	✓	○	✓
INFINITI EX37	I50	2008-2012	BCM	※	✓	✓	○	✓
INFINITI EX37	I50	2008-2012	ENGINE	✓	✓	✓	※	✓
INFINITI EX37	I50	2008-2012	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI EX37	I50	2008-2012	IPDM_ER	○	✓	✓	○	✓
INFINITI EX37	I50	2008-2012	METER	※	✓	✓	○	✓
INFINITI EX37	I50	2008-2012	MULTI_AV	※	✓	✓	○	✓
INFINITI EX37	I50	2008-2012	SONAR	✓	✓	✓	○	✓
INFINITI EX37	I50	2008-2012	TRANSMISSION	✓	✓	✓	※	✓
INFINITI FX35/FX45	S50	2003-2008	ABS	✓	✓	✓	○	✓
INFINITI FX35/FX45	S50	2003-2008	ACM	✓	✓	✓	○	✓
INFINITI FX35/FX45	S50	2003-2008	ACTIVE SUS	✓	✓	✓	✓	✓
INFINITI FX35/FX45	S50	2003-2008	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI FX35/FX45	S50	2003-2008	AIRBAG	✓	✓	✓	✓	✓
INFINITI FX35/FX45	S50	2003-2008	AIR LEVELIZER	✓	✓	✓	○	✓

INFINITI FX35/FX45	S50	2003-2008	AIR PRESSURE MONITOR	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	ALL_MODE_AWD4WD	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	ASCD	○	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	AUTO_DRIVE_POS	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	AUTO_SLIDE_DOOR	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	BCM	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	DIFF_LOCK	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	DISTANCE_CONTROL	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	DIU	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	ENGINE	√	√	√	※	√
INFINITI FX35/FX45	S50	2003-2008	EPS	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	E_4WD	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	HEAD_LAMP_LEVELIZER	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	HVAC	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	INTELLIGENT_KEY	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	IPDM_ER	○	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	IVMS	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	LDW	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	METER	○	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	MOTORO_CONTROL_UNIT	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	MOTOR_ASSIST	○	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	MULTI_AV	○	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	NATS_IMMU	○	√	√	○	○
INFINITI FX35/FX45	S50	2003-2008	RASHICAS	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	REARVIEW_CAMERA	√	○	○	○	√
INFINITI FX35/FX45	S50	2003-2008	S/BLIND_CAMERA	√	○	○	○	√
INFINITI FX35/FX45	S50	2003-2008	SMART_ENTRANCE	○	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	SONAR	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	TBDADAS_ICC	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	TBDAMV	√	√	√	○	√
INFINITI FX35/FX45	S50	2003-2008	TCS	√	√	√	√	√
INFINITI FX35/FX45	S50	2003-2008	TRANSMISSION	√	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	ABS	√	√	√	※	√
INFINITI FX35/FX50	S51	2008-2013	ACCELE_PEDAL_ACT	√	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	ADAPTIVE_LIGHT	√	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	AIRBAG	√	√	√	√	√
INFINITI FX35/FX50	S51	2008-2013	AIR_PRESSURE_MONITOR	√	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	ALL_MODE_AWD4WD	√	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	AUTO_DRIVE_POS	√	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	BCM	※	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	ENGINE	√	√	√	※	√
INFINITI FX35/FX50	S51	2008-2013	E_SUS	√	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	HEAD_LAMP_LEVELIZER	√	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	IPDM_ER	○	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	LANE_CAMERA	√	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	METER	※	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	MULTI_AV	※	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	ODS					
INFINITI FX35/FX50	S51	2008-2013	PRECRASH_SEATBELT	√	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	PTC_HEATER	√	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	REARVIEW_CAMERA	√	○	○	○	√
INFINITI FX35/FX50	S51	2008-2013	SONAR	√	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	ICC/ADAS	√	√	√	※	√
INFINITI FX35/FX50	S51	2008-2013	AVM	√	√	√	○	√
INFINITI FX35/FX50	S51	2008-2013	TOTAL_ILLUM_C/U	√	○	○	○	√
INFINITI FX35/FX50	S51	2008-2013	TRANSMISSION	√	√	√	※	√
INFINITI FX35/FX50/FX30d	S51	2011	ABS	√	√	√	※	√
INFINITI FX35/FX50/FX30d	S51	2011	ACCELE_PEDAL_ACT	√	√	√	○	√
INFINITI FX35/FX50/FX30d	S51	2011	AIRBAG	√	√	√	○	√
INFINITI FX35/FX50/FX30d	S51	2011	AIR_PRESSURE_MONITOR	√	√	√	○	√
INFINITI FX35/FX50/FX30d	S51	2011	ALL_MODE_AWD4WD	√	√	√	○	√
INFINITI FX35/FX50/FX30d	S51	2011	AUTO_DRIVE_POS	√	√	√	○	√
INFINITI FX35/FX50/FX30d	S51	2011	BCM	※	√	√	○	√
INFINITI FX35/FX50/FX30d	S51	2011	ENGINE	√	√	√	※	√
INFINITI FX35/FX50/FX30d	S51	2011	E_SUS	√	√	√	○	√
INFINITI FX35/FX50/FX30d	S51	2011	HEAD_LAMP_LEVELIZER	√	√	√	○	√
INFINITI FX35/FX50/FX30d	S51	2011	IPDM_ER	○	√	√	○	√
INFINITI FX35/FX50/FX30d	S51	2011	METER	※	√	√	○	√

INFINITI FX35/FX50/FX30d	S51	2011	MULTI_AV	※	√	√	○	√
INFINITI FX35/FX50/FX30d	S51	2011	SONAR	√	√	√	○	√
INFINITI FX35/FX50/FX30d	S51	2011	TOTAL_ILUMM_CU	√	○	○	○	√
INFINITI FX35/FX50/FX30d	S51	2011	TRANSMISSION	√	√	√	※	√
INFINITI EX37	S51	2012	ABS	√	√	√	※	√
INFINITI EX37	S51	2012	ACCELE PEDAL ACT	√	√	√	○	√
INFINITI EX37	S51	2012	ADAPTIVE LIGHT	√	√	√	○	√
INFINITI EX37	S51	2012	AIRBAG	√	√	√	√	√
INFINITI EX37	S51	2012	AIR PRESSURE MONITOR	√	√	√	○	√
INFINITI EX37	S51	2012	ALL_MODE_AWD4WD	√	√	√	○	√
INFINITI EX37	S51	2012	AUTO_DRIVE_POS	√	√	√	○	√
INFINITI EX37	S51	2012	BCM	※	√	√	○	√
INFINITI EX37	S51	2012	ENGINE	√	√	√	※	√
INFINITI EX37	S51	2012	E_SUS	√	√	√	○	√
INFINITI EX37	S51	2012	HEAD_LAMP_LEVELIZER	√	√	√	○	√
INFINITI EX37	S51	2012	IPDM_ER	○	√	√	○	√
INFINITI EX37	S51	2012	LANE CAMERA	√	√	√	○	√
INFINITI EX37	S51	2012	METER	※	√	√	○	√
INFINITI EX37	S51	2012	MULTI_AV	※	√	√	○	√
INFINITI EX37	S51	2012	SONAR	√	√	√	○	√
INFINITI EX37	S51	2012	ICC/ADAS	√	√	√	※	√
INFINITI EX37	S51	2012	AVM	√	√	√	○	√
INFINITI EX37	S51	2012	TOTAL ILLUM C/U	√	○	○	○	√
INFINITI EX37	S51	2012	TRANSMISSION	√	√	√	※	√
INFINITI FX37/FX50	S51	2008-2012	ABS	√	√	√	※	√
INFINITI FX37/FX50	S51	2008-2012	ACCELE PEDAL ACT	√	√	√	○	√
INFINITI FX37/FX50	S51	2008-2012	ADAPTIVE LIGHT	√	√	√	○	√
INFINITI FX37/FX50	S51	2008-2012	AIRBAG	√	√	√	√	√
INFINITI FX37/FX50	S51	2008-2012	AIR PRESSURE MONITOR	√	√	√	○	√
INFINITI FX37/FX50	S51	2008-2012	ALL_MODE_AWD4WD	√	√	√	○	√
INFINITI FX37/FX50	S51	2008-2012	AUTO_DRIVE_POS	√	√	√	○	√
INFINITI FX37/FX50	S51	2008-2012	BCM	※	√	√	○	√
INFINITI FX37/FX50	S51	2008-2012	ENGINE	√	√	√	※	√
INFINITI FX37/FX50	S51	2008-2012	E_SUS	√	√	√	○	√
INFINITI FX37/FX50	S51	2008-2012	HEAD_LAMP_LEVELIZER	√	√	√	○	√
INFINITI FX37/FX50	S51	2008-2012	IPDM_ER	○	√	√	○	√
INFINITI FX37/FX50	S51	2008-2012	LANE CAMERA	√	√	√	○	√
INFINITI FX37/FX50	S51	2008-2012	METER	※	√	√	○	√
INFINITI FX37/FX50	S51	2008-2012	MULTI_AV	※	√	√	○	√
INFINITI FX37/FX50	S51	2008-2012	SONAR	√	√	√	○	√
INFINITI FX37/FX50	S51	2008-2012	ICC/ADAS	√	√	√	※	√
INFINITI FX37/FX50	S51	2008-2012	TOTAL ILLUM C/U	√	○	○	○	√
INFINITI FX37/FX50	S51	2008-2012	TRANSMISSION	√	√	√	※	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	ABS	√	√	√	※	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	ACCELE_PEDAL_ACT	√	√	√	○	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	ADAPTIVE_LIGHT	√	√	√	○	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	AIRBAG	√	√	√	√	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	AIR_PRESSURE_MONITOR	√	√	√	○	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	ALL_MODE_AWD4WD	√	√	√	○	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	AUTO_DRIVE_POS	√	√	√	○	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	BCM	※	√	√	○	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	ENGINE	√	√	√	※	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	E_SUS	√	√	√	○	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	HEAD_LAMP_LEVELIZER	√	√	√	○	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	IPDM_ER	○	√	√	○	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	LANE CAMERA	√	√	√	○	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	METER	※	√	√	○	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	MULTI_AV	※	√	√	○	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	PRECRASH_SEATBELT	√	√	√	○	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	REARVIEW_CAMERA	√	○	○	○	√

INFINITI FX37/FX50/FX30d	S51	2009-2012	SONAR	√	√	√	○	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	ICC/ADAS	√	√	√	※	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	AVM	√	√	√	○	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	TOTAL ILLUM C/U	√	○	○	○	√
INFINITI FX37/FX50/FX30d	S51	2009-2012	TRANSMISSION	√	√	√	※	√
INFINITI G20	P11	1999-2002	ABS	√	√	√	○	√
INFINITI G20	P11	1999-2002	ACM	√	√	√	○	√
INFINITI G20	P11	1999-2002	ACTIVE SUS	√	√	√	√	√
INFINITI G20	P11	1999-2002	ADAPTIVE LIGHT	√	√	√	○	√
INFINITI G20	P11	1999-2002	AIRBAG	√	√	√	√	√
INFINITI G20	P11	1999-2002	AIR LEVELIZER	√	√	√	○	√
INFINITI G20	P11	1999-2002	AIR PRESSURE MONITOR	√	√	√	○	√
INFINITI G20	P11	1999-2002	ALL MODE AWD4WD	√	√	√	○	√
INFINITI G20	P11	1999-2002	ASCD	○	√	√	○	√
INFINITI G20	P11	1999-2002	AUTO DRIVE POS	√	√	√	○	√
INFINITI G20	P11	1999-2002	AUTO SLIDE DOOR	√	√	√	○	√
INFINITI G20	P11	1999-2002	BCM	√	√	√	○	√
INFINITI G20	P11	1999-2002	DIFF LOCK	√	√	√	○	√
INFINITI G20	P11	1999-2002	DISTANCE CONTROL	√	√	√	○	√
INFINITI G20	P11	1999-2002	DIU	√	√	√	○	√
INFINITI G20	P11	1999-2002	ENGINE	√	√	√	※	√
INFINITI G20	P11	1999-2002	EPS	√	√	√	○	√
INFINITI G20	P11	1999-2002	E 4WD	√	√	√	○	√
INFINITI G20	P11	1999-2002	HEAD LAMP LEVELIZER	√	√	√	○	√
INFINITI G20	P11	1999-2002	HVAC	√	√	√	○	√
INFINITI G20	P11	1999-2002	INTELLIGENT KEY	√	√	√	○	√
INFINITI G20	P11	1999-2002	IPDM ER	○	√	√	○	√
INFINITI G20	P11	1999-2002	IVMS	√	√	√	○	√
INFINITI G20	P11	1999-2002	LDW	√	√	√	○	√
INFINITI G20	P11	1999-2002	METER	○	√	√	○	√
INFINITI G20	P11	1999-2002	MOTORO CONTROL UNIT	√	√	√	○	√
INFINITI G20	P11	1999-2002	MOTOR ASSIST	○	√	√	○	√
INFINITI G20	P11	1999-2002	MULTI AV	○	√	√	○	√
INFINITI G20	P11	1999-2002	NATS IMMU	○	√	√	○	○
INFINITI G20	P11	1999-2002	RASHICAS	√	√	√	○	√
INFINITI G20	P11	1999-2002	REARVIEW CAMERA	√	○	○	○	√
INFINITI G20	P11	1999-2002	S/BLIND CAMERA	√	○	○	○	√
INFINITI G20	P11	1999-2002	SMART ENTRANCE	○	√	√	○	√
INFINITI G20	P11	1999-2002	SONAR	√	√	√	○	√
INFINITI G20	P11	1999-2002	TBDADAS ICC	√	√	√	○	√
INFINITI G20	P11	1999-2002	TBDAYM	√	√	√	○	√
INFINITI G20	P11	1999-2002	TCS	√	√	√	√	√
INFINITI G20	P11	1999-2002	TRANSMISSION	√	√	√	○	√
INFINITI G20	CA33	2002-2004	ABS	√	√	√	○	√
INFINITI G20	CA33	2002-2004	ACM	√	√	√	○	√
INFINITI G20	CA33	2002-2004	ACTIVE SUS	√	√	√	√	√
INFINITI G20	CA33	2002-2004	ADAPTIVE LIGHT	√	√	√	○	√
INFINITI G20	CA33	2002-2004	AIRBAG	√	√	√	√	√
INFINITI G20	CA33	2002-2004	AIR LEVELIZER	√	√	√	○	√
INFINITI G20	CA33	2002-2004	AIR PRESSURE MONITOR	√	√	√	○	√
INFINITI G20	CA33	2002-2004	ALL MODE AWD4WD	√	√	√	○	√
INFINITI G20	CA33	2002-2004	ASCD	○	√	√	○	√
INFINITI G20	CA33	2002-2004	AUTO DRIVE POS	√	√	√	○	√
INFINITI G20	CA33	2002-2004	AUTO SLIDE DOOR	√	√	√	○	√
INFINITI G20	CA33	2002-2004	BCM	√	√	√	○	√
INFINITI G20	CA33	2002-2004	DIFF LOCK	√	√	√	○	√
INFINITI G20	CA33	2002-2004	DISTANCE CONTROL	√	√	√	○	√
INFINITI G20	CA33	2002-2004	DIU	√	√	√	○	√
INFINITI G20	CA33	2002-2004	ENGINE	√	√	√	※	√
INFINITI G20	CA33	2002-2004	EPS	√	√	√	○	√
INFINITI G20	CA33	2002-2004	E 4WD	√	√	√	○	√
INFINITI G20	CA33	2002-2004	HEAD LAMP LEVELIZER	√	√	√	○	√
INFINITI G20	CA33	2002-2004	HVAC	√	√	√	○	√
INFINITI G20	CA33	2002-2004	INTELLIGENT KEY	√	√	√	○	√
INFINITI G20	CA33	2002-2004	IPDM ER	○	√	√	○	√
INFINITI G20	CA33	2002-2004	IVMS	√	√	√	○	√
INFINITI G20	CA33	2002-2004	LDW	√	√	√	○	√
INFINITI G20	CA33	2002-2004	METER	○	√	√	○	√
INFINITI G20	CA33	2002-2004	MOTORO CONTROL UNIT	√	√	√	○	√
INFINITI G20	CA33	2002-2004	MOTOR ASSIST	○	√	√	○	√
INFINITI G20	CA33	2002-2004	MULTI AV	○	√	√	○	√
INFINITI G20	CA33	2002-2004	NATS IMMU	○	√	√	○	○
INFINITI G20	CA33	2002-2004	RASHICAS	√	√	√	○	√
INFINITI G20	CA33	2002-2004	REARVIEW CAMERA	√	○	○	○	√
INFINITI G20	CA33	2002-2004	S/BLIND CAMERA	√	○	○	○	√
INFINITI G20	CA33	2002-2004	SMART ENTRANCE	○	√	√	○	√

INFINITI G20	CA33	2002-2004	SONAR	✓	✓	✓	○	✓
INFINITI G20	CA33	2002-2004	TBDADAS ICC	✓	✓	✓	○	✓
INFINITI G20	CA33	2002-2004	TBDAVM	✓	✓	✓	○	✓
INFINITI G20	CA33	2002-2004	TCS	✓	✓	✓	✓	✓
INFINITI G20	CA33	2002-2004	TRANSMISSION	✓	✓	✓	○	✓
INFINITI G25/G37 Sedan	V36	2009-2012	4WASCAN	✓	✓	✓	○	✓
INFINITI G25/G37 Sedan	V36	2009-2012	ABS	✓	✓	✓	※	✓
INFINITI G25/G37 Sedan	V36	2009-2012	ACCELE_PEDAL_ACT	✓	✓	✓	○	✓
INFINITI G25/G37 Sedan	V36	2009-2012	ADAPTIVE_LIGHT	✓	✓	✓	○	✓
INFINITI G25/G37 Sedan	V36	2009-2012	AIRBAG	✓	✓	✓	✓	✓
INFINITI G25/G37 Sedan	V36	2009-2012	ALL_MODE_AWD4WD	✓	✓	✓	○	✓
INFINITI G25/G37 Sedan	V36	2009-2012	AUTO_DRIVE_POS	✓	✓	✓	○	✓
INFINITI G25/G37 Sedan	V36	2009-2012	BCM	※	✓	✓	○	✓
INFINITI G25/G37 Sedan	V36	2009-2012	CONVERTIBLE_ROOF	✓	✓	✓	○	✓
INFINITI G25/G37 Sedan	V36	2009-2012	ENGINE	✓	✓	✓	※	✓
INFINITI G25/G37 Sedan	V36	2009-2012	HEAD_LAMP_LEVELIZER	✓	✓	✓	○	✓
INFINITI G25/G37 Sedan	V36	2009-2012	IPDM_ER	○	✓	✓	○	✓
INFINITI G25/G37 Sedan	V36	2009-2012	METER	※	✓	✓	○	✓
INFINITI G25/G37 Sedan	V36	2009-2012	MULTI_AV	※	✓	✓	○	✓
INFINITI G25/G37 Sedan	V36	2009-2012	POP_UP_HOOD	✓	✓	✓	○	✓
INFINITI G25/G37 Sedan	V36	2009-2012	PRECRASH_SEATBELT	✓	✓	✓	○	✓
INFINITI G25/G37 Sedan	V36	2009-2012	SONAR	✓	✓	✓	○	✓
INFINITI G25/G37 Sedan	V36	2009-2012	ICC/ADAS	✓	✓	✓	※	✓
INFINITI G25/G37 Sedan	V36	2009-2012	TRANSMISSION	✓	✓	✓	※	✓
INFINITI G35 Coupe	CV35	2003-2007	ABS	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	ACM	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	ACTIVE_SUS	✓	✓	✓	✓	✓
INFINITI G35 Coupe	CV35	2003-2007	ADAPTIVE_LIGHT	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	AIRBAG	✓	✓	✓	✓	✓
INFINITI G35 Coupe	CV35	2003-2007	AIR_LEVELIZER	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	AIR_PRESSURE_MONITOR	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	ALL_MODE_AWD4WD	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	ASCD	○	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	AUTO_DRIVE_POS	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	AUTO_SLIDE_DOOR	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	BCM	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	DIFF_LOCK	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	DISTANCE_CONTROL	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	DIU	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	ENGINE	✓	✓	✓	※	✓
INFINITI G35 Coupe	CV35	2003-2007	EPS	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	E_4WD	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	HEAD_LAMP_LEVELIZER	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	HVAC	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	INTELLIGENT_KEY	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	IPDM_ER	○	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	IVMS	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	LDW	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	METER	○	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	MOTORO_CONTROL_UNIT	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	MOTOR_ASSIST	○	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	MULTI_AV	○	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	NATS_IMMU	○	✓	✓	○	○
INFINITI G35 Coupe	CV35	2003-2007	RASHICAS	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	REARVIEW_CAMERA	✓	○	○	○	✓
INFINITI G35 Coupe	CV35	2003-2007	S/BLIND_CAMERA	✓	○	○	○	✓
INFINITI G35 Coupe	CV35	2003-2007	SMART_ENTRANCE	○	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	SONAR	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	TBDADAS ICC	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	TBDAVM	✓	✓	✓	○	✓
INFINITI G35 Coupe	CV35	2003-2007	TCS	✓	✓	✓	✓	✓
INFINITI G35 Coupe	CV35	2003-2007	TRANSMISSION	✓	✓	✓	○	✓

INFINITI G35 Sedan	V35	2003-2008	ABS	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	ACM	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	ACTIVE SUS	✓	✓	✓	✓	✓
INFINITI G35 Sedan	V35	2003-2008	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	AIRBAG	✓	✓	✓	✓	✓
INFINITI G35 Sedan	V35	2003-2008	AIR LEVELIZER	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	AIR PRESSURE MONITOR	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	ALL_MODE_AWD4WD	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	ASCD	○	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	AUTO_DRIVE_POS	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	AUTO_SLIDE_DOOR	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	BCM	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	DIFF LOCK	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	DISTANCE CONTROL	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	DIU	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	ENGINE	✓	✓	✓	※	✓
INFINITI G35 Sedan	V35	2003-2008	EPS	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	E 4WD	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	HEAD_LAMP_LEVELIZER	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	HVAC	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	INTELLIGENT KEY	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	IPDM_ER	○	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	IVMS	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	LDW	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	METER	○	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	MOTORO_CONTROL_UNIT	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	MOTOR_ASSIST	○	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	MULTI_AV	○	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	NATS_IMMJ	○	✓	✓	○	○
INFINITI G35 Sedan	V35	2003-2008	RASHICAS	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	REARVIEW_CAMERA	✓	○	○	○	✓
INFINITI G35 Sedan	V35	2003-2008	S/BLIND_CAMERA	✓	○	○	○	✓
INFINITI G35 Sedan	V35	2003-2008	SMART_ENTRANCE	○	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	SONAR	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	TBDADAS_ICC	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	TBDAYM	✓	✓	✓	○	✓
INFINITI G35 Sedan	V35	2003-2008	TCS	✓	✓	✓	✓	✓
INFINITI G35 Sedan	V35	2003-2008	TRANSMISSION	✓	✓	✓	○	✓
INFINITI G37 Convertible	HV36	2009-2013	4WASCAN	✓	✓	✓	○	✓
INFINITI G37 Convertible	HV36	2009-2013	ABS	✓	✓	✓	※	✓
INFINITI G37 Convertible	HV36	2009-2013	ACCELE_PEDAL_ACT	✓	✓	✓	○	✓
INFINITI G37 Convertible	HV36	2009-2013	ADAPTIVE_LIGHT	✓	✓	✓	○	✓
INFINITI G37 Convertible	HV36	2009-2013	AIRBAG	✓	✓	✓	✓	✓
INFINITI G37 Convertible	HV36	2009-2013	ALL_MODE_AWD4WD	✓	✓	✓	○	✓
INFINITI G37 Convertible	HV36	2009-2013	AUTO_DRIVE_POS	✓	✓	✓	○	✓
INFINITI G37 Convertible	HV36	2009-2013	BCM	※	✓	✓	○	✓
INFINITI G37 Convertible	HV36	2009-2013	CONVERTIBLE_ROOF	✓	✓	✓	○	✓
INFINITI G37 Convertible	HV36	2009-2013	ENGINE	✓	✓	✓	※	✓
INFINITI G37 Convertible	HV36	2009-2013	HEAD_LAMP_LEVELIZER	✓	✓	✓	○	✓
INFINITI G37 Convertible	HV36	2009-2013	IPDM_ER	○	✓	✓	○	✓
INFINITI G37 Convertible	HV36	2009-2013	METER	※	✓	✓	○	✓
INFINITI G37 Convertible	HV36	2009-2013	MULTI_AV	※	✓	✓	○	✓
INFINITI G37 Convertible	HV36	2009-2013	POP_UP_HOOD	✓	✓	✓	○	✓
INFINITI G37 Convertible	HV36	2009-2013	PRECRASH_SEATBELT	✓	✓	✓	○	✓
INFINITI G37 Convertible	HV36	2009-2013	SONAR	✓	✓	✓	○	✓
INFINITI G37 Convertible	HV36	2009-2013	ICC/ADAS	✓	✓	✓	※	✓
INFINITI G37 Convertible	HV36	2009-2013	TRANSMISSION	✓	✓	✓	※	✓
INFINITI G37 Coupe	CV36	2007-2013	4WASCAN	✓	✓	✓	○	✓
INFINITI G37 Coupe	CV36	2007-2013	ABS	✓	✓	✓	※	✓
INFINITI G37 Coupe	CV36	2007-2013	ACCELE_PEDAL_ACT	✓	✓	✓	○	✓
INFINITI G37 Coupe	CV36	2007-2013	ADAPTIVE_LIGHT	✓	✓	✓	○	✓
INFINITI G37 Coupe	CV36	2007-2013	AIRBAG	✓	✓	✓	✓	✓

INFINITI G37 Coupe	CV36	2007-2013	ALL MODE AWD4WD	✓	✓	✓	○	✓
INFINITI G37 Coupe	CV36	2007-2013	AUTO DRIVE POS	✓	✓	✓	○	✓
INFINITI G37 Coupe	CV36	2007-2013	BCM	※	✓	✓	○	✓
INFINITI G37 Coupe	CV36	2007-2013	CONVERTIBLE ROOF	✓	✓	✓	○	✓
INFINITI G37 Coupe	CV36	2007-2013	ENGINE	✓	✓	✓	※	✓
INFINITI G37 Coupe	CV36	2007-2013	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI G37 Coupe	CV36	2007-2013	IPDM ER	○	✓	✓	○	✓
INFINITI G37 Coupe	CV36	2007-2013	METER	※	✓	✓	○	✓
INFINITI G37 Coupe	CV36	2007-2013	MULTI AV	※	✓	✓	○	✓
INFINITI G37 Coupe	CV36	2007-2013	POP UP HOOD	✓	✓	✓	○	✓
INFINITI G37 Coupe	CV36	2007-2013	PRECRASH SEATBELT	✓	✓	✓	○	✓
INFINITI G37 Coupe	CV36	2007-2013	SONAR	✓	✓	✓	○	✓
INFINITI G37 Coupe	CV36	2007-2013	ICC/ADAS	✓	✓	✓	※	✓
INFINITI G37 Coupe	CV36	2007-2013	TRANSMISSION	✓	✓	✓	※	✓
INFINITI G37 Sedan	V36	2008-2011	4WASCAN	✓	✓	✓	○	✓
INFINITI G37 Sedan	V36	2008-2011	ABS	✓	✓	✓	※	✓
INFINITI G37 Sedan	V36	2008-2011	ACCELE PEDAL ACT	✓	✓	✓	○	✓
INFINITI G37 Sedan	V36	2008-2011	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI G37 Sedan	V36	2008-2011	AIRBAG	✓	✓	✓	✓	✓
INFINITI G37 Sedan	V36	2008-2011	ALL MODE AWD4WD	✓	✓	✓	○	✓
INFINITI G37 Sedan	V36	2008-2011	AUTO DRIVE POS	✓	✓	✓	○	✓
INFINITI G37 Sedan	V36	2008-2011	BCM	※	✓	✓	○	✓
INFINITI G37 Sedan	V36	2008-2011	CONVERTIBLE ROOF	✓	✓	✓	○	✓
INFINITI G37 Sedan	V36	2008-2011	ENGINE	✓	✓	✓	※	✓
INFINITI G37 Sedan	V36	2008-2011	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI G37 Sedan	V36	2008-2011	IPDM ER	○	✓	✓	○	✓
INFINITI G37 Sedan	V36	2008-2011	METER	※	✓	✓	○	✓
INFINITI G37 Sedan	V36	2008-2011	MULTI AV	※	✓	✓	○	✓
INFINITI G37 Sedan	V36	2008-2011	POP UP HOOD	✓	✓	✓	○	✓
INFINITI G37 Sedan	V36	2008-2011	PRECRASH SEATBELT	✓	✓	✓	○	✓
INFINITI G37 Sedan	V36	2008-2011	SONAR	✓	✓	✓	○	✓
INFINITI G37 Sedan	V36	2008-2011	ICC/ADAS	✓	✓	✓	※	✓
INFINITI G37 Sedan	V36	2008-2011	TRANSMISSION	✓	✓	✓	※	✓
INFINITI I30	CA32	1996-2001	ABS	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	ACM	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	ACTIVE SUS	✓	✓	✓	✓	✓
INFINITI I30	CA32	1996-2001	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	AIRBAG	✓	✓	✓	✓	✓
INFINITI I30	CA32	1996-2001	AIR LEVELIZER	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	AIR PRESSURE MONITOR	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	ALL MODE AWD4WD	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	ASCD	○	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	AUTO DRIVE POS	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	AUTO SLIDE DOOR	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	BCM	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	DIFF LOCK	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	DISTANCE CONTROL	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	DIU	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	ENGINE	✓	✓	✓	※	✓
INFINITI I30	CA32	1996-2001	EPS	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	E 4WD	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	HVAC	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	INTELLIGENT KEY	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	IPDM ER	○	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	IVMS	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	LDW	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	METER	○	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	MOTORO CONTROL UNIT	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	MOTOR ASSIST	○	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	MULTI AV	○	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	NATS IMMUI	○	✓	✓	○	○
INFINITI I30	CA32	1996-2001	RASHICAS	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	REARVIEW CAMERA	✓	○	○	○	✓
INFINITI I30	CA32	1996-2001	S/BLIND CAMERA	✓	○	○	○	✓
INFINITI I30	CA32	1996-2001	SMART ENTRANCE	○	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	SONAR	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	TBDADAS ICC	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	TBDAVM	✓	✓	✓	○	✓
INFINITI I30	CA32	1996-2001	TCS	✓	✓	✓	✓	✓
INFINITI I30	CA32	1996-2001	TRANSMISSION	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	ABS	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	ACM	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	ACTIVE SUS	✓	✓	✓	✓	✓
INFINITI I35	CA33	2002-2004	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	AIRBAG	✓	✓	✓	✓	✓
INFINITI I35	CA33	2002-2004	AIR LEVELIZER	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	AIR PRESSURE MONITOR	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	ALL MODE AWD4WD	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	ASCD	○	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	AUTO DRIVE POS	✓	✓	✓	○	✓

INFINITI I35	CA33	2002-2004	AUTO SLIDE DOOR	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	BCM	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	DIFF LOCK	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	DISTANCE CONTROL	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	DIU	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	ENGINE	✓	✓	✓	※	✓
INFINITI I35	CA33	2002-2004	EPS	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	E 4WD	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	HVAC	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	INTELLIGENT KEY	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	IPDM ER	○	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	IVMS	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	LDW	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	METER	○	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	MOTORO CONTROL UNIT	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	MOTOR ASSIST	○	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	MULTI AV	○	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	NATS IMMU	○	✓	✓	○	○
INFINITI I35	CA33	2002-2004	RASHICAS	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	REARVIEW CAMERA	✓	○	○	○	✓
INFINITI I35	CA33	2002-2004	S/BLIND CAMERA	✓	○	○	○	✓
INFINITI I35	CA33	2002-2004	SMART ENTRANCE	○	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	SONAR	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	TBDADAS ICC	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	TBDAYM	✓	✓	✓	○	✓
INFINITI I35	CA33	2002-2004	TCS	✓	✓	✓	✓	✓
INFINITI I35	CA33	2002-2004	TRANSMISSION	✓	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	ABS	✓	✓	✓	※	✓
INFINITI IX35	L50	2012-2013	ACCELE PEDAL ACT	✓	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	AIRBAG	✓	✓	✓	✓	✓
INFINITI IX35	L50	2012-2013	ALL MODE AWD4WD	✓	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	AUTO DRIVE POS	✓	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	BCM	※	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	ENGINE	✓	✓	✓	※	✓
INFINITI IX35	L50	2012-2013	EPS	✓	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	HVAC	✓	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	IPDM E/R	○	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	LANE CAMERA	✓	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	LASER/RADAR	✓	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	METER	※	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	MULTI AV	※	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	PRECRASH SEATBELT	✓	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	SIDE RADAR LEFT	✓	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	SIDE RADAR RIGHT	✓	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	SONAR	✓	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	ICC/ADAS	✓	✓	✓	※	✓
INFINITI IX35	L50	2012-2013	AVM	✓	✓	✓	○	✓
INFINITI IX35	L50	2012-2013	TRANSMISSION	✓	✓	✓	※	✓
INFINITI M25/M37	Y51	2010-2012	AWASCAN	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	ABS	✓	✓	✓	※	✓
INFINITI M25/M37	Y51	2010-2012	ACCELE PEDAL ACT	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	AIRBAG	✓	✓	✓	✓	✓
INFINITI M25/M37	Y51	2010-2012	AIR PRESSURE MONITOR	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	ALL MODE AWD4WD	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	AUTO DRIVE POS	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	BCM	※	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	CONVERTIBLE ROOF	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	ENGINE	✓	✓	✓	※	✓
INFINITI M25/M37	Y51	2010-2012	E SUS	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	HVAC	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	IPDM E/R	○	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	LANE CAMERA	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	LASER/RADAR	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	METER	※	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	MULTI AV	※	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	POP UP HOOD	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	PRECRASH SEATBELT	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	SIDE RADAR LEFT	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	SIDE RADAR RIGHT	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	SONAR	✓	✓	✓	○	✓
INFINITI M25/M37	Y51	2010-2012	ICC/ADAS	✓	✓	✓	※	✓
INFINITI M25/M37	Y51	2010-2012	TRANSMISSION	✓	✓	✓	※	✓
INFINITI M35/M45	Y50	2006-2010	ABS	✓	✓	✓	※	✓
INFINITI M35/M45	Y50	2006-2010	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI M35/M45	Y50	2006-2010	AIRBAG	✓	✓	✓	✓	✓
INFINITI M35/M45	Y50	2006-2010	AIR PRESSURE MONITOR	✓	✓	✓	○	✓
INFINITI M35/M45	Y50	2006-2010	ALL MODE AWD4WD	✓	✓	✓	○	✓

INFINITI M35/M45	Y50	2006-2010	AUTO DRIVE POS	✓	✓	✓	○	✓
INFINITI M35/M45	Y50	2006-2010	BCM	※	✓	✓	○	✓
INFINITI M35/M45	Y50	2006-2010	ENGINE	✓	✓	✓	※	✓
INFINITI M35/M45	Y50	2006-2010	INTELLIGENT KEY	✓	✓	✓	○	✓
INFINITI M35/M45	Y50	2006-2010	IPDME/R	○	✓	✓	○	✓
INFINITI M35/M45	Y50	2006-2010	LASER/RADAR	✓	✓	✓	○	✓
INFINITI M35/M45	Y50	2006-2010	METER	※	✓	✓	○	✓
INFINITI M35/M45	Y50	2006-2010	MULTI AV	※	✓	✓	○	✓
INFINITI M35/M45	Y50	2006-2010	PRECRASH SEATBELT	✓	✓	✓	○	✓
INFINITI M35/M45	Y50	2006-2010	REARVIEW CAMERA	✓	○	○	○	✓
INFINITI M35/M45	Y50	2006-2010	SONAR	✓	✓	✓	○	✓
INFINITI M35/M45	Y50	2006-2010	ICC/ADAS	✓	✓	✓	※	✓
INFINITI M35/M45	Y50	2006-2010	TRANSMISSION	✓	✓	✓	※	✓
INFINITI M37	Y51	2012	4WASCAN	✓	✓	✓	○	✓
INFINITI M37	Y51	2012	ABS	✓	✓	✓	※	✓
INFINITI M37	Y51	2012	ACCELE PEDAL ACT	✓	✓	✓	○	✓
INFINITI M37	Y51	2012	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI M37	Y51	2012	AIRBAG	✓	✓	✓	✓	✓
INFINITI M37	Y51	2012	AIR PRESSURE MONITOR	✓	✓	✓	○	✓
INFINITI M37	Y51	2012	ALL_MODE AWD4WD	✓	✓	✓	○	✓
INFINITI M37	Y51	2012	AUTO DRIVE POS	✓	✓	✓	○	✓
INFINITI M37	Y51	2012	BCM	※	✓	✓	○	✓
INFINITI M37	Y51	2012	ENGINE	✓	✓	✓	※	✓
INFINITI M37	Y51	2012	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI M37	Y51	2012	HVAC	✓	✓	✓	○	✓
INFINITI M37	Y51	2012	IPDME/R	○	✓	✓	○	✓
INFINITI M37	Y51	2012	LANE CAMERA	✓	✓	✓	○	✓
INFINITI M37	Y51	2012	LASER/RADAR	✓	✓	✓	○	✓
INFINITI M37	Y51	2012	METER	※	✓	✓	○	✓
INFINITI M37	Y51	2012	MULTI AV	※	✓	✓	○	✓
INFINITI M37	Y51	2012	SIDE RADAR LEFT	✓	✓	✓	○	✓
INFINITI M37	Y51	2012	SIDE RADAR RIGHT	✓	✓	✓	○	✓
INFINITI M37	Y51	2012	SONAR	✓	✓	✓	○	✓
INFINITI M37	Y51	2012	ICC	✓	✓	✓	※	✓
INFINITI M37	Y51	2012	TRANSMISSION	✓	✓	✓	※	✓
INFINITI M37/M56	Y51	2010-2013	4WASCAN	✓	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	ABS	✓	✓	✓	※	✓
INFINITI M37/M56	Y51	2010-2013	ACCELE PEDAL ACT	✓	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	AIRBAG	✓	✓	✓	✓	✓
INFINITI M37/M56	Y51	2010-2013	AIR PRESSURE MONITOR	✓	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	ALL_MODE AWD4WD	✓	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	AUTO DRIVE POS	✓	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	BCM	※	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	ENGINE	✓	✓	✓	※	✓
INFINITI M37/M56	Y51	2010-2013	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	HVAC	✓	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	IPDME/R	○	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	LANE CAMERA	✓	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	LASER/RADAR	✓	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	METER	※	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	MULTI AV	※	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	SIDE RADAR LEFT	✓	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	SIDE RADAR RIGHT	✓	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	SONAR	✓	✓	✓	○	✓
INFINITI M37/M56	Y51	2010-2013	ICC	✓	✓	✓	※	✓
INFINITI M37/M56	Y51	2010-2013	TRANSMISSION	✓	✓	✓	※	✓
INFINITI M37/M56/M30d	Y51	2010-2012	4WASCAN	✓	✓	✓	○	✓
INFINITI M37/M56/M30d	Y51	2010-2012	ABS	✓	✓	✓	※	✓
INFINITI M37/M56/M30d	Y51	2010-2012	ACCELE_PEDAL_ACT	✓	✓	✓	○	✓
INFINITI M37/M56/M30d	Y51	2010-2012	ADAPTIVE_LIGHT	✓	✓	✓	○	✓
INFINITI M37/M56/M30d	Y51	2010-2012	AIRBAG	✓	✓	✓	✓	✓
INFINITI M37/M56/M30d	Y51	2010-2012	AIR_PRESSURE_MONITOR	✓	✓	✓	○	✓
INFINITI M37/M56/M30d	Y51	2010-2012	ALL_MODE_AWD4WD	✓	✓	✓	○	✓
INFINITI M37/M56/M30d	Y51	2010-2012	AUTO_DRIVE_POS	✓	✓	✓	○	✓
INFINITI M37/M56/M30d	Y51	2010-2012	BCM	※	✓	✓	○	✓
INFINITI M37/M56/M30d	Y51	2010-2012	CONVERTIBLE_ROOF	✓	✓	✓	○	✓
INFINITI M37/M56/M30d	Y51	2010-2012	DIGITAL_SOUND_CONTROL	✓	✓	✓	○	✓

INFINITI M37/M56/M30d	Y51	2010-2012	ENGINE	√	√	√	※	√
INFINITI M37/M56/M30d	Y51	2010-2012	E_SUS	√	√	√	○	√
INFINITI M37/M56/M30d	Y51	2010-2012	EV/HEV	√	√	√	√	√
INFINITI M37/M56/M30d	Y51	2010-2012	HEAD LAMP LEVELIZER	√	√	√	○	√
INFINITI M37/M56/M30d	Y51	2010-2012	HVAC	√	√	√	○	√
INFINITI M37/M56/M30d	Y51	2010-2012	IPDM E/R	○	√	√	○	√
INFINITI M37/M56/M30d	Y51	2010-2012	LANE CAMERA	√	√	√	○	√
INFINITI M37/M56/M30d	Y51	2010-2012	LASER/RADAR	√	√	√	○	√
INFINITI M37/M56/M30d	Y51	2010-2012	HV BATTERY	√	√	√	√	√
INFINITI M37/M56/M30d	Y51	2010-2012	METER	※	√	√	○	√
INFINITI M37/M56/M30d	Y51	2010-2012	MOTORO_CONTROL_UNIT	√	√	√	※	√
INFINITI M37/M56/M30d	Y51	2010-2012	MULTI_AV	※	√	√	○	√
INFINITI M37/M56/M30d	Y51	2010-2012	POP_UP_HOOD	√	√	√	○	√
INFINITI M37/M56/M30d	Y51	2010-2012	PRECRASH_SEATBELT	√	√	√	○	√
INFINITI M37/M56/M30d	Y51	2010-2012	SIDE_RADAR_LEFT	√	√	√	○	√
INFINITI M37/M56/M30d	Y51	2010-2012	SIDE_RADAR_RIGHT	√	√	√	○	√
INFINITI M37/M56/M30d	Y51	2010-2012	SONAR	√	√	√	○	√
INFINITI M37/M56/M30d	Y51	2010-2012	ICC	√	√	√	※	√
INFINITI M37/M56/M30d	Y51	2010-2012	TRANSMISSION	√	√	√	※	√
INFINITI M45	Y34	2003-2005	ABS	√	√	√	○	√
INFINITI M45	Y34	2003-2005	ACM	√	√	√	○	√
INFINITI M45	Y34	2003-2005	ACTIVE SUS	√	√	√	√	√
INFINITI M45	Y34	2003-2005	ADAPTIVE LIGHT	√	√	√	○	√
INFINITI M45	Y34	2003-2005	AIRBAG	√	√	√	√	√
INFINITI M45	Y34	2003-2005	AIR LEVELIZER	√	√	√	○	√
INFINITI M45	Y34	2003-2005	AIR PRESSURE MONITOR	√	√	√	○	√
INFINITI M45	Y34	2003-2005	ALL_MODE AWD4WD	√	√	√	○	√
INFINITI M45	Y34	2003-2005	ASCD	○	√	√	○	√
INFINITI M45	Y34	2003-2005	AUTO DRIVE POS	√	√	√	○	√
INFINITI M45	Y34	2003-2005	AUTO SLIDE DOOR	√	√	√	○	√
INFINITI M45	Y34	2003-2005	BCM	√	√	√	○	√
INFINITI M45	Y34	2003-2005	DIFF LOCK	√	√	√	○	√
INFINITI M45	Y34	2003-2005	DISTANCE CONTROL	√	√	√	○	√
INFINITI M45	Y34	2003-2005	DII	√	√	√	○	√
INFINITI M45	Y34	2003-2005	ENGINE	√	√	√	※	√
INFINITI M45	Y34	2003-2005	EPS	√	√	√	○	√
INFINITI M45	Y34	2003-2005	E 4WD	√	√	√	○	√
INFINITI M45	Y34	2003-2005	HEAD LAMP LEVELIZER	√	√	√	○	√
INFINITI M45	Y34	2003-2005	HVAC	√	√	√	○	√
INFINITI M45	Y34	2003-2005	INTELLIGENT KEY	√	√	√	○	√
INFINITI M45	Y34	2003-2005	IPDM ER	○	√	√	○	√
INFINITI M45	Y34	2003-2005	IVMS	√	√	√	○	√
INFINITI M45	Y34	2003-2005	LDW	√	√	√	○	√
INFINITI M45	Y34	2003-2005	METER	○	√	√	○	√
INFINITI M45	Y34	2003-2005	MOTORO_CONTROL_UNIT	√	√	√	○	√
INFINITI M45	Y34	2003-2005	MOTOR ASSIST	○	√	√	○	√
INFINITI M45	Y34	2003-2005	MULTI_AV	○	√	√	○	√
INFINITI M45	Y34	2003-2005	NATS IMMUI	○	√	√	○	○
INFINITI M45	Y34	2003-2005	RASHICAS	√	√	√	○	√
INFINITI M45	Y34	2003-2005	REARVIEW CAMERA	√	○	○	○	√
INFINITI M45	Y34	2003-2005	S/BLIND CAMERA	√	○	○	○	√
INFINITI M45	Y34	2003-2005	SMART ENTRANCE	○	√	√	○	√
INFINITI M45	Y34	2003-2005	SONAR	√	√	√	○	√
INFINITI M45	Y34	2003-2005	TBDADAS ICC	√	√	√	○	√
INFINITI M45	Y34	2003-2005	TBDAYM	√	√	√	○	√
INFINITI M45	Y34	2003-2005	TCS	√	√	√	√	√
INFINITI M45	Y34	2003-2005	TRANSMISSION	√	√	√	○	√
INFINITI Q45	R50	ALL	ABS	√	√	√	√	√
INFINITI Q45	R50	ALL	ACM	√	√	√	○	√
INFINITI Q45	R50	ALL	ACTIVE SUS	√	√	√	√	√
INFINITI Q45	R50	ALL	ADAPTIVE LIGHT	√	√	√	○	√
INFINITI Q45	R50	ALL	AIRBAG	√	√	√	√	√

INFINITI Q45	F50	ALL	AIR LEVELIZER	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	AIR PRESSURE MONITOR	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	ALL MODE AWD4WD	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	ASCD	○	✓	✓	○	✓
INFINITI Q45	F50	ALL	AUTO DRIVE POS	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	AUTO SLIDE DOOR	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	BCM	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	DIFF LOCK	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	DISTANCE CONTROL	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	DIU	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	ENGINE	✓	✓	✓	※	✓
INFINITI Q45	F50	ALL	EPS	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	E 4WD	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	HVAC	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	INTELLIGENT KEY	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	IPDM ER	○	✓	✓	○	✓
INFINITI Q45	F50	ALL	IYMS	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	LDW	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	METER	○	✓	✓	○	✓
INFINITI Q45	F50	ALL	MOTORO CONTROL UNIT	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	MOTOR ASSIST	○	✓	✓	○	✓
INFINITI Q45	F50	ALL	MULTI AV	○	✓	✓	○	✓
INFINITI Q45	F50	ALL	NATS IMMU	○	✓	✓	○	○
INFINITI Q45	F50	ALL	RASHICAS	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	REARVIEW CAMERA	✓	○	○	○	✓
INFINITI Q45	F50	ALL	S/BLIND CAMERA	✓	○	○	○	✓
INFINITI Q45	F50	ALL	SMART ENTRANCE	○	✓	✓	○	✓
INFINITI Q45	F50	ALL	SONAR	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	TBDADAS ICC	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	TBDAVM	✓	✓	✓	○	✓
INFINITI Q45	F50	ALL	TCS	✓	✓	✓	✓	✓
INFINITI Q45	F50	ALL	TRANSMISSION	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	ABS	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	ACM	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	ACTIVE SUS	✓	✓	✓	✓	✓
INFINITI QX4	F50	1997-2003	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	AIRBAG	✓	✓	✓	✓	✓
INFINITI QX4	F50	1997-2003	AIR LEVELIZER	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	AIR PRESSURE MONITOR	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	ALL MODE AWD4WD	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	ASCD	○	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	AUTO DRIVE POS	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	AUTO SLIDE DOOR	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	BCM	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	DIFF LOCK	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	DISTANCE CONTROL	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	DIU	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	ENGINE	✓	✓	✓	※	✓
INFINITI QX4	F50	1997-2003	EPS	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	E 4WD	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	HVAC	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	INTELLIGENT KEY	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	IPDM ER	○	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	IYMS	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	LDW	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	METER	○	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	MOTORO CONTROL UNIT	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	MOTOR ASSIST	○	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	MULTI AV	○	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	NATS IMMU	○	✓	✓	○	○
INFINITI QX4	F50	1997-2003	RASHICAS	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	REARVIEW CAMERA	✓	○	○	○	✓
INFINITI QX4	F50	1997-2003	S/BLIND CAMERA	✓	○	○	○	✓
INFINITI QX4	F50	1997-2003	SMART ENTRANCE	○	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	SONAR	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	TBDADAS ICC	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	TBDAVM	✓	✓	✓	○	✓
INFINITI QX4	F50	1997-2003	TCS	✓	✓	✓	✓	✓
INFINITI QX4	F50	1997-2003	TRANSMISSION	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	ABS	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	ACM	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	ACTIVE SUS	✓	✓	✓	✓	✓
INFINITI QX56	JA60	2004-2010	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	AIRBAG	✓	✓	✓	✓	✓
INFINITI QX56	JA60	2004-2010	AIR LEVELIZER	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	AIR PRESSURE MONITOR	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	ALL MODE AWD4WD	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	ASCD	○	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	AUTO DRIVE POS	✓	✓	✓	○	✓

INFINITI QX56	JA60	2004-2010	AUTO SLIDE DOOR	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	BCM	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	DIFF LOCK	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	DISTANCE CONTROL	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	DIU	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	ENGINE	✓	✓	✓	※	✓
INFINITI QX56	JA60	2004-2010	EPS	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	E 4WD	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	HVAC	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	INTELLIGENT KEY	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	IPDM ER	○	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	IVMS	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	LDW	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	METER	○	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	MOTORO CONTROL UNIT	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	MOTOR ASSIST	○	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	MULTI AV	○	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	NATS IMMUI	○	✓	✓	○	○
INFINITI QX56	JA60	2004-2010	RASHICAS	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	REARVIEW CAMERA	✓	○	○	○	✓
INFINITI QX56	JA60	2004-2010	S/BLIND CAMERA	✓	○	○	○	✓
INFINITI QX56	JA60	2004-2010	SMART ENTRANCE	○	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	SONAR	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	TBDADAS ICC	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	TBDAYM	✓	✓	✓	○	✓
INFINITI QX56	JA60	2004-2010	TCS	✓	✓	✓	✓	✓
INFINITI QX56	JA60	2004-2010	TRANSMISSION	✓	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	ABS	✓	✓	✓	※	✓
INFINITI QX56	Z62	2010-2012	ACCELE PEDAL ACT	✓	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	ADAPTIVE LIGHT	✓	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	AIRBAG	✓	✓	✓	✓	✓
INFINITI QX56	Z62	2010-2012	AIR PRESSURE MONITOR	✓	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	ALL MODE AWD4WD	✓	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	AUTO DRIVE POS	✓	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	BCM	※	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	ENGINE	✓	✓	✓	※	✓
INFINITI QX56	Z62	2010-2012	E SUS	✓	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	HEAD LAMP LEVELIZER	✓	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	HVAC	✓	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	IPDM E/R	○	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	LANE CAMERA	✓	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	LASER/RADAR	✓	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	METER	※	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	MULTI AV	※	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	PRECRASH SEATBELT	✓	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	REARVIEW CAMERA	✓	○	○	○	✓
INFINITI QX56	Z62	2010-2012	SIDE RADAR LEFT	✓	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	SIDE RADAR RIGHT	✓	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	SONAR	✓	✓	✓	○	✓
INFINITI QX56	Z62	2010-2012	ICC	✓	✓	✓	※	✓
INFINITI QX56	Z62	2010-2012	TRANSMISSION	✓	✓	✓	※	✓